
ADVANTEST[®]

ADVANTEST CORPORATION

***R3681 Series OPT64
Single-Carrier General-Purpose
Modulation Analysis Software
User's Guide***

MANUAL NUMBER FOE-8440217A00

Applicable Models

R3681

R3671

TABLE OF CONTENTS

1.	INTRODUCTION	1-1
1.1	Outline of This Manual	1-1
1.2	Product Overview	1-2
1.3	Other Manuals Relating to This Instrument	1-2
1.4	Conventions of Notation Used in This Document	1-3
1.5	Trademarks and Registered Trademarks	1-4
2.	BEFORE OPERATING	2-1
2.1	If a Fault Should Occur	2-1
2.2	Removing the Case	2-1
2.3	Overcurrent Protection	2-1
2.4	Hard Disk Drive	2-1
2.5	Handling the Touch Screen	2-2
2.6	Getting the Software Running with Stability	2-2
2.7	Transporting	2-2
2.8	Electromagnetic Interference	2-3
2.9	Before Turning On	2-3
2.10	Removing and Attaching the Front Panel	2-3
2.11	Limitations Imposed when Using Windows XP	2-5
3.	SETUP	3-1
3.1	Unpacking Inspection	3-1
3.2	Locating This Instrument	3-2
3.2.1	Operating Environment	3-2
3.2.2	Prevention of Electrostatic Buildup	3-3
3.3	Connecting Accessories	3-4
3.3.1	Connecting the Keyboard and Mouse	3-4
3.4	Supply Description	3-5
3.4.1	Check the Supply Power	3-5
3.4.2	Connecting the Power Cable	3-5
3.5	Operation Check	3-7
4.	MEASUREMENT EXAMPLES	4-1
4.1	Modulation Accuracy Measurement of the QPSK Signal	4-1
4.2	EVM Measurement of the DUT by Using the Equalizing Filter	4-6
5.	MENU MAP, FUNCTIONAL EXPLANATION	5-1
5.1	Menu Index	5-1
5.2	Switching Communication Systems	5-3
5.3	Function Bar	5-3
5.4	Soft Menu Bar	5-3

Table of Contents

5.5	Description of the Function of Each Key	5-4
5.5.1	{MEAS SETUP}	5-4
5.5.2	{DISPLAY}	5-10
5.5.3	{SCALE}	5-13
5.5.4	{MKR}	5-14
5.5.5	{INPUT}	5-15
5.5.6	{TRIGGER}	5-16
5.5.7	{LEVEL}	5-17
5.5.8	{FREQ}	5-18
5.5.9	Measurement Tool Bar	5-19
6.	SCPI COMMAND REFERENCE	6-1
6.1	Command Reference Format	6-1
6.2	Common Commands	6-3
6.3	List of Commands	6-4
6.3.1	Subsystem-SYSTEM	6-4
6.3.2	Subsystem-INPUT	6-4
6.3.3	Subsystem-SENSE	6-5
6.3.4	Subsystem-TRIGGER	6-7
6.3.5	Subsystem-INITIATE	6-7
6.3.6	Subsystem-CALCULATE	6-7
6.3.7	Subsystem-DISPLAY	6-8
6.3.8	Subsystem-MMEMORY	6-9
6.3.9	Subsystem-MEASURE	6-9
6.3.10	Subsystem-READ	6-12
6.3.11	Subsystem-FETCH	6-14
6.3.12	Subsystem-FORMAT	6-16
6.3.13	Subsystem-STATUS	6-16
6.3.14	Subsystem-HCOPY	6-16
6.4	Status Register	6-17
7.	PERFORMANCE VERIFICATION	7-1
7.1	Test Signal Specifications	7-1
7.2	Test Procedures	7-3
7.2.1	RF Input Test Signal Measurement	7-3
7.2.1.1	8PSK Measurement	7-3
7.2.1.2	256QAM Measurement	7-4
7.2.1.3	MSK Measurement	7-5
7.2.1.4	FSK Measurement	7-6
7.2.2	IQ Input Test Signal Measurement	7-8
7.2.2.1	8PSK Measurement	7-8
7.2.2.2	256QAM Measurement	7-9
7.2.2.3	MSK Measurement	7-10
7.2.2.4	FSK Measurement	7-11
7.3	Test Data Record Sheet	7-12
7.3.1	RF Input	7-12
7.3.1.1	8PSK Signal	7-12
7.3.1.2	256QAM Signal	7-12

7.3.1.3	MSK Signal	7-12
7.3.1.4	FSK Signal	7-13
7.3.2	IQ Input	7-14
7.3.2.1	8PSK Signal	7-14
7.3.2.2	256QAM Signal	7-14
7.3.2.3	MSK Signal	7-14
7.3.2.4	FSK Signal	7-14
8.	SPECIFICATIONS	8-1
8.1	Conditions	8-1
8.1.1	Instrument Conditions	8-1
8.1.2	Conditions of Signal to Be Measured	8-2
8.2	Single-Carrier General-Purpose Modulation Analysis Performance	8-3
8.2.1	RF Input	8-3
8.2.1.1	8PSK Signal	8-3
8.2.1.2	256QAM Signal	8-4
8.2.1.3	MSK Signal	8-4
8.2.1.4	FSK Signal	8-5
8.2.2	IQ Input	8-6
8.2.2.1	8PSK Signal	8-6
8.2.2.2	256QAM Signal	8-6
8.2.2.3	MSK Signal	8-6
8.2.2.4	FSK Signal	8-7
	APPENDIX	A-1
A.1	Technical Notes	A-1
A.1.1	How to Calculate Measurement Values	A-1
A.1.2	Symbol Mapping	A-4
A.1.2.1	BPSK	A-4
A.1.2.2	QPSK($\pi/4$ DQPSK)	A-4
A.1.2.3	8PSK	A-5
A.1.2.4	16QAM (Differential Code OFF)	A-5
A.1.2.5	16QAM (Differential Code ON)	A-6
A.1.2.6	32QAM (Differential Code OFF)	A-7
A.1.2.7	32QAM (Differential Code ON)	A-7
A.1.2.8	64QAM (Differential Code OFF)	A-8
A.1.2.9	64QAM (Differential Code ON)	A-8
A.1.2.10	128QAM (Differential Code OFF)	A-9
A.1.2.11	128QAM (Differential Code ON)	A-10
A.1.2.12	256QAM (Differential Code OFF)	A-11
A.1.2.13	256QAM (Differential Code ON)	A-12
A.1.2.14	MSK, FSK	A-12
A.1.3	Synchronous Word Setting	A-13
A.1.4	Cutoff of Filter Type Sinc	A-14
A.1.5	Tx Power and Peak Power in Total Result	A-14
A.1.6	A/D Capture Length and Analysis Length	A-15
A.1.7	Standard Setting parameter	A-16
A.1.8	File Format of the User Filter	A-17
A.1.9	Demodulated Data Saving Function	A-19

Table of Contents

A.2	Error Message List	A-21
A.3	Warning Message List	A-22
	ALPHABETICAL INDEX	I-1

LIST OF ILLUSTRATIONS

No.	Title	Page
3-1	Operating Environment	3-2
3-2	Countermeasures against Static Electricity from the Human Body	3-3
3-3	Countermeasures against Static Electricity from the Work Floor	3-3
3-4	Countermeasures against Static Electricity from the Workbench	3-4
3-5	Connecting the Keyboard and Mouse	3-4
3-6	Connecting the Power Cable	3-6
3-7	POWER Switch	3-7
3-8	Initial Setup Screen	3-8
3-9	Autocalibration	3-9
4-1	Modulation Accuracy Measurement Connection Diagram	4-1
4-2	[Input Setup] Dialog Box	4-2
4-3	[Measurement Parameters Setup] Dialog Box	4-3
4-4	[Synchronous Parameters Setup] Dialog Box	4-4
4-5	[Filter Parameters Setup] Dialog Box	4-5
4-6	Modulation Accuracy Measurement Results	4-5
4-7	Connection Diagram using the Equalizing Filter	4-6
4-8	[Input Setup] Dialog Box	4-7
4-9	[Measurement Parameters Setup] Dialog Box	4-8
4-10	[Synchronous Parameters Setup] Dialog Box	4-8
4-11	[Filter Parameters Setup] Dialog Box	4-9
4-12	Modulation Accuracy Measurement Results	4-10
4-13	Transfer Characteristics Measurement Results	4-11
4-14	DUT Measurement Results	4-12
6-1	Status Registers	6-17
7-1	Connection Diagram of Signal Source (RF Input)	7-3
7-2	Connection Diagram of Signal Source (IQ Input)	7-8
A-1	Error Vector Magnitude, Magnitude Error, Phase Error	A-3
A-2	BPSK Mapping	A-4
A-3	QPSK Mapping	A-4
A-4	8PSK Mapping	A-5
A-5	16QAM Mapping (Differential Code OFF)	A-5
A-6	16QAM Mapping (Differential Code ON)	A-6
A-7	32QAM Mapping (Differential Code OFF)	A-7
A-8	32QAM Mapping (Differential Code ON)	A-7
A-9	64QAM Mapping (Differential Code OFF)	A-8
A-10	64QAM Mapping (Differential Code ON)	A-8
A-11	128QAM Mapping (Differential Code OFF)	A-9
A-12	128QAM Mapping (Differential Code ON)	A-10
A-13	125QAM Mapping (Differential Code OFF)	A-11
A-14	256QAM Mapping (Differential Code ON)	A-12
A-15	Synchronous Parameters Setup Dialog Box	A-13
A-16	QPSK Signal Power Spectrum for each Cutoff	A-14

List of Illustrations

No.	Title	Page
A-17	Example of Acquiring the Burst Signal into the A/D Memory	A-15

LIST OF TABLES

No.	Title	Page
3-1	Standard Accessory	3-1
3-2	ESD Countermeasures	3-3
3-3	Power Supply Specifications	3-5
4-1	Signal Specifications	4-1
7-1	Test Signal Specifications	7-1
A-1	MSK and FSK Mapping	A-12
A-2	Standard Setting Parameter	A-16
A-3	Error Message List	A-21
A-4	Warning Message List	A-22

1. INTRODUCTION

This chapter describes the outline of this manual and the product overview of the R3681 series signal analyzer option 64 Single-Carrier General-Purpose Modulation Analysis Software.

1.1 Outline of This Manual

The outline of each chapter is shown below:

For basic operating methods, functions and the remote programming method of the signal analyzer, refer to "1.3 Other Manuals Relating to This Instrument."

Chapter 1. INTRODUCTION	Describes the outline of this manual and the product overview.
Chapter 2. BEFORE OPERATING	Provides preliminary tips on using this instrument. Read this chapter before using this instrument.
Chapter 3. SETUP	Describes how to set up this instrument. After installing this instrument in position, switch it on to make sure that it starts successfully.
Chapter 4. MEASUREMENT EXAMPLES	Describes example measurements.
Chapter 5. MENU MAP, FUNCTIONAL EXPLANATION	Describes the menu configuration and functions of the soft keys.
Chapter 6. SCPI COMMAND REFERENCE	SCPI command reference. The command reference describes the commands in order of function. The following items are described: <ul style="list-style-type: none"> • Command format • Function description • Parameters • Query response
Chapter 7. PERFORMANCE VERIFICATION	Describes the performance verification test procedures for option 64.
Chapter 8. SPECIFICATIONS	Shows the specifications of option 64.
APPENDIX	Describes operation principles and the error code table.

1.2 Product Overview

The single-carrier general-purpose modulation analysis option is software that performs the modulation analysis of the single-carrier modulated signal.

This option includes the following features.

- Analyzing the modulation accuracy such as the phase error, frequency error, and EVM (Error Vector Magnitude) by setting the symbol rate and modulation format.
- Analyzing the frequency characteristics of the transmitter and EVM of the DUT by using the equalizing function.
- Analyzing the quadrature error and the IQ gain imbalance of the quadrature modulator/demodulator.

1.3 Other Manuals Relating to This Instrument

Manuals which relate to this instrument include:

- User's Guide (Part Code: {ER3681SERIES/U}, English)
Describes how to setup the R3681 Series Signal Analyzer, how to perform procedures such as, basic operations, applied measurements, and maintenance, and describes the functions, specifications of the R3681 Series Signal Analyzer.
- Programming Guide (Part Code: {ER3681SERIES/P}, English)
Describes how to program the R3681 Series Signal Analyzer to automate measurement sequences and includes a remote control overview, SCPI command references, and sample application programs.
- Performance Test Guide (Part Code: {ER3681SERIES/T}, English)
Describes how to check the performance of the R3681 Series Signal Analyzer and includes performance test procedures and specifications of the R3681 Series Signal Analyzer.

1.4 Conventions of Notation Used in This Document

In this document, hard keys, touch-screen buttons and menus are represented by the following symbols:

Hard keys

“Hard keys” are hardware keys which are on the panel.

Sample Indicates a hard key labeled “Sample.”
Example: **START**, **STOP**

Touch-screen system menus

[Sample] Indicates a touch-screen menu, tab, button or dialog box that is labeled “Sample” and that is selected or executed when touched.
Example: **[File]** menu, **[Normal]** tab, **[Option]** button

Touch-screen function buttons

{Sample} Indicates a touch-screen button labeled “Sample.”
Example: **{FREQ}** button, **{SWEEP}** button

Touch-screen side menu

Sample Indicates a touch-screen side menu labeled “Sample.”
Example: **Center** key, **Span** key

Touch-screen system menu key operation

[File]→[Save As...] Indicates that you need to touch the **[File]** menu and then select **[Save As...]**.

Sequential key operation

{FREQ}, Center Indicates that you need to touch the **{FREQ}** button and then touch the **Center** key.

Toggle key operation

ΔMarker On/Off (On) Indicates that you need to touch the **ΔMarker On/Off** key to turn on the ΔMarker.

NOTE: Screen displays and diagrams such as external view of the main unit in this manual are those of the R3681 in the R3681 series.

1.5 Trademarks and Registered Trademarks

1.5 Trademarks and Registered Trademarks

- Microsoft® and Windows® are trademarks or registered trademarks of Microsoft Corporation in the United States and other countries.
- Other product and company names referenced herein are trademarks or registered trademarks of their respective owners.

2. BEFORE OPERATING

This chapter describes important information on using this instrument. Read this chapter before using this instrument.

2.1 If a Fault Should Occur

If smoke, strange smells, or strange noises are detected, switch off the power, disconnect the power cable and contact either your dealer or Advantest immediately.

2.2 Removing the Case

The case should not be opened except by qualified Advantest service personnel.

WARNING: *This instrument contains high-voltage and high-temperature parts. Electrical shocks or burns may result if handled incorrectly.*

2.3 Overcurrent Protection

This instrument is protected from overcurrent flow by a power breaker. Located on the rear panel, the power breaker automatically interrupts the power supply when an overcurrent flows through this instrument. When the power breaker has turned off, turn off the power supply and disconnect the power cable from the AC power. Then, call upon your dealer or us for repair services to fix a possible fault that has occurred in this instrument.

2.4 Hard Disk Drive

This instrument has a built-in hard disk drive. When handling the hard disk drive, take notice of these instructions.

- Do not cause impact or vibration damage to the hard disk drive.
Damaging the disk increasing the chances of the disk malfunctioning or failing during operation.
- Do not switch off this instrument while the HDD access lamp is lit.
The data being accessed may become corrupt.

CAUTION: *We do not assume any responsibility for the loss or corruption of data stored on the hard disk drive that might result from the disk becoming damaged.*

2.5 Handling the Touch Screen

2.5 Handling the Touch Screen

This instrument has a touch screen. When handling the touch screen, take notice of these instructions.

- Do not give apply excessive force to the screen. The screen is made from glass and may crack.
- Use the stylus pen included with this instrument to operate the screen. Using a tool with a hard-point (such as a mechanical pencil or ballpoint) may scratch the screen surface.

2.6 Getting the Software Running with Stability

The R3681 Series Signal Analyzer has Microsoft Windows XP pre-installed.

The measuring function of this instrument is dependent on the Windows environment. Do not alter the Windows operating environment in any way other than as described in this manual.

This instrument is not a data processor. Operate it only as described in this manual.

1. Prohibited actions

- Installing other application programs.
- Changing or deleting items in the control panel (except as described in "A.2 Installing the Printer Driver" and "A.3 Setting up the Network" of R3681 Series User's Guide).
- Creating new files or editing existing files on the C drive.
- Operating other application programs during the measurement.
- Upgrading the Windows operating system.
- If this instrument functions incorrectly because of any of the above, re-install the system using the system recovery disk.
For more information on the system recovery procedure, refer to section 8.7, "System Recovery Procedure" in the R3681 Series User's Guide.

2. Computer viruses

Depending on the operating environment, the system may become infected by a computer virus. To protect the system, we recommended taking the following countermeasures:

- Perform a virus check before loading any file or inserting any media from an outside source.
- Make sure that any network used has safety measures against computer viruses before connecting this instrument.

[If infected with a computer virus:]

- Delete all files on the D drive. Re-install the system using the recovery disk.
For more information on the system recovery procedure, refer to section 8.7, "System Recovery Procedure" of R3681 Series User's Guide.

2.7 Transporting

Extreme care as described below must be taken when carrying this instrument.

- This instrument is heavy and must be carried by two or more persons, or on a transportation cart.
- If using a cart to move this instrument, ensure the instrument is secure.

2.8 Electromagnetic Interference

This instrument may cause electromagnetic interference and affect television and radio reception.

If the electromagnetic interference is reduced when this instrument's is turned off, then this instrument is the cause of the problem.

Electromagnetic interference may be prevented by doing the following:

- Changing the direction of the antenna of the television or radio.
- Placing this instrument on the other side of the television or radio.
- Placing this instrument away from the television or radio.
- Using different lines power outlets for this instrument and the television or radio.

2.9 Before Turning On

Do not connect a DUT to this instrument when turning on.

2.10 Removing and Attaching the Front Panel


This instrument can be used separately after removing the panel.

When removing the panel, take notice of these instructions.

MEMO: *To use this instrument after removing the panel, a connecting cable is required (sold separately).*

- If this instrument's power is turned on, make sure that this instrument has stopped operating, turn off the power, and remove the power cable.
- When removing or attaching the panel, take care not to catch your fingers.
- Place this instrument on a flat and steady table when removing or attaching the panel.
- Remove the four screws that are exposed on the side of the front panel of this instrument.
- When removing the screws, steady the panel so that it will not fall.
- After all four screws have been removed, pull the panel forward.
- Remove the cable connecting the panel to the instrument.
- Replace the cable with an appropriate cable.
- If any screws become lost, use the following types of screw.
 - For the 2 screws on the key side: flat-head Phillips screws M4X35 (steel or stainless steel)
 - For the 2 screws on the liquid-crystal display: flat-head Phillips screws M4X14 (steel or stainless steel)

2.10 Removing and Attaching the Front Panel



2.11 Limitations Imposed when Using Windows XP

END-USER LICENSE AGREEMENT

- You have acquired a device ("INSTRUMENT") that includes software licensed by [ADVANTEST] from Microsoft Licensing Inc. or its affiliates ("MS"). Those installed software products of MS origin, as well as associated media, printed materials, and "online" or electronic documentation ("SOFTWARE") are protected by international intellectual property laws and treaties. The SOFTWARE is licensed, not sold. All rights reserved.
- IF YOU DO NOT AGREE TO THIS END USER LICENSE AGREEMENT ("EULA"), DO NOT USE THE INSTRUMENT OR COPY THE SOFTWARE. INSTEAD, PROMPTLY CONTACT [ADVANTEST] FOR INSTRUCTIONS ON RETURN OF THE UNUSED INSTRUMENT(S) FOR A REFUND. ANY USE OF THE SOFTWARE, INCLUDING BUT NOT LIMITED TO USE ON THE INSTRUMENT, WILL CONSTITUTE YOUR AGREEMENT TO THIS EULA (OR RATIFICATION OF ANY PREVIOUS CONSENT).
- **GRANT OF SOFTWARE LICENSE.** This EULA grants you the following license:
 - You may use the SOFTWARE only on the INSTRUMENT.
 - **NOT FAULT TOLERANT.** THE SOFTWARE IS NOT FAULT TOLERANT. [ADVANTEST] HAS INDEPENDENTLY DETERMINED HOW TO USE THE SOFTWARE IN THE INSTRUMENT, AND MS HAS RELIED UPON [ADVANTEST] TO CONDUCT SUFFICIENT TESTING TO DETERMINE THAT THE SOFTWARE IS SUITABLE FOR SUCH USE.
 - **NO WARRANTIES FOR THE SOFTWARE. THE SOFTWARE is provided "AS IS" and with all faults. THE ENTIRE RISK AS TO SATISFACTORY QUALITY, PERFORMANCE, ACCURACY, AND EFFORT (INCLUDING LACK OF NEGLIGENCE) IS WITH YOU. ALSO, THERE IS NO WARRANTY AGAINST INTERFERENCE WITH YOUR ENJOYMENT OF THE SOFTWARE OR AGAINST INFRINGEMENT. IF YOU HAVE RECEIVED ANY WARRANTIES REGARDING THE INSTRUMENT OR THE SOFTWARE, THOSE WARRANTIES DO NOT ORIGINATE FROM, AND ARE NOT BINDING ON, MS.**
 - **No Liability for Certain Damages. EXCEPT AS PROHIBITED BY LAW, MS SHALL HAVE NO LIABILITY FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL OR INCIDENTAL DAMAGES ARISING FROM OR IN CONNECTION WITH THE USE OR PERFORMANCE OF THE SOFTWARE. THIS LIMITATION SHALL APPLY EVEN IF ANY REMEDY FAILS OF ITS ESSENTIAL PURPOSE. IN NO EVENT SHALL MS BE LIABLE FOR ANY AMOUNT IN EXCESS OF U.S. TWO HUNDRED FIFTY DOLLARS (U.S.\$250.00).**
 - **Limitations on Reverse Engineering, Decompilation, and Disassembly.** You may not reverse engineer, decompile, or disassemble the SOFTWARE, except and only to the extent that such activity is expressly permitted by applicable law notwithstanding this limitation.
 - **SOFTWARE TRANSFER ALLOWED BUT WITH RESTRICTIONS.** You may permanently transfer rights under this EULA only as part of a permanent sale or transfer of the INSTRUMENT, and only if the recipient agrees to this EULA. If the SOFTWARE is an upgrade, any transfer must also include all prior versions of the SOFTWARE.
 - **EXPORT RESTRICTIONS.** You acknowledge that SOFTWARE is of US-origin. You agree to comply with all applicable international and national laws that apply to the SOFTWARE, including the U.S. Export Administration Regulations, as well as end-user, end-use and country destination restrictions issued by U.S. and other governments. For additional information on exporting the SOFTWARE, see <http://www.microsoft.com/exporting/>.
- ┌ **Installation and Use.** The SOFTWARE may not be used by more than two (2) processors at any one time on the INSTRUMENT. You may permit a maximum of ten (10) computers or other electronic devices (each a "Client") to connect to the INSTRUMENT to utilize the services of the SOFTWARE solely for file and print services, internet information services, and remote access (including connection sharing and telephony services). The ten (10) connection maximum includes any indirect connections made through "multiplexing" or other software or hardware which pools or aggregates connections. Except as otherwise permitted in the NetMeeting/Remote Assistance/Remote Desktop Features terms below, you may not use a Client to use, access, display or run the SOFTWARE, the SOFTWARE's user interface or other executable software residing on the INSTRUMENT.
- ┌ If you use the INSTRUMENT to access or utilize the services or functionality of Microsoft Windows Server products (such as Microsoft Windows NT Server 4.0 (all editions) or Microsoft Windows 2000 Server (all editions)), or use the INSTRUMENT to permit workstation or computing devices to access or utilize the services or functionality of Microsoft Windows Server products, you may be required to obtain a Client Access License for the INSTRUMENT and/or each such workstation or computing device. Please refer to the end user license agreement for your Microsoft Windows Server product for additional information.
- ┌ **Restricted Uses.** The SOFTWARE is not designed or intended for use or resale in hazardous environments requiring fail-safe performance, such as in the operation of nuclear facilities, aircraft navigation or communication systems, air traffic control, or other devices or systems in which a malfunction of the SOFTWARE would result in foreseeable risk of injury or death to the operator of the device or system, or to others.
- ┌ **Restricted Functionality.** You are licensed to use the SOFTWARE to provide only the limited functionality (specific tasks or processes) for which the INSTRUMENT has been designed and marketed by

2.11 Limitations Imposed when Using Windows XP

[ADVANTEST]. This license specifically prohibits any other use of the software programs or functions, or inclusion of additional software programs or functions, on the INSTRUMENT.

- **Security Updates.** Content providers are using the digital rights management technology ("Microsoft DRM") contained in this SOFTWARE to protect the integrity of their content ("Secure Content") so that their intellectual property, including copyright, in such content is not misappropriated. Owners of such Secure Content ("Secure Content Owners") may, from time to time, request MS, Microsoft Corporation or their subsidiaries to provide security related updates to the Microsoft DRM components of the SOFTWARE ("Security Updates") that may affect your ability to copy, display and/or play Secure Content through Microsoft software or third party applications that utilize Microsoft DRM. You therefore agree that, if you elect to download a license from the Internet which enables your use of Secure Content, MS, Microsoft Corporation or their subsidiaries may, in conjunction with such license, also download onto your INSTRUMENT such Security Updates that a Secure Content Owner has requested that MS, Microsoft Corporation or their subsidiaries distribute. MS, Microsoft Corporation or their subsidiaries will not retrieve any personally identifiable information, or any other information, from your INSTRUMENT by downloading such Security Updates.
- || **NetMeeting/Remote Assistance/Remote Desktop Features.** The SOFTWARE may contain NetMeeting, Remote Assistance, and Remote Desktop technologies that enable the SOFTWARE or other applications installed on the INSTRUMENT to be used remotely between two or more computing devices, even if the SOFTWARE or application is installed on only one INSTRUMENT. You may use NetMeeting, Remote Assistance, and Remote Desktop with all Microsoft products; provided however, use of these technologies with certain Microsoft products may require an additional license. For both Microsoft products and non-Microsoft products, you should consult the license agreement accompanying the applicable product or contact the applicable licensor to determine whether use of NetMeeting, Remote Assistance, or Remote Desktop is permitted without an additional license.
- || **Consent to Use of Data.** You agree that MS, Microsoft Corporation and their affiliates may collect and use technical information gathered in any manner as part of product support services related to the SOFTWARE. MS, Microsoft Corporation and their affiliates may use this information solely to improve their products or to provide customized services or technologies to you. MS, Microsoft Corporation and their affiliates may disclose this information to others, but not in a form that personally identifies you.
- **Internet Gaming/Update Features.** If the SOFTWARE provides, and you choose to utilize, the Internet gaming or update features within the SOFTWARE, it is necessary to use certain computer system, hardware, and software information to implement the features. By using these features, you explicitly authorize MS, Microsoft Corporation and/or their designated agent to use this information solely to improve their products or to provide customized services or technologies to you. MS or Microsoft Corporation may disclose this information to others, but not in a form that personally identifies you.
- || **Internet-Based Services Components.** The SOFTWARE may contain components that enable and facilitate the use of certain Internet-based services. You acknowledge and agree that MS, Microsoft Corporation or their affiliates may automatically check the version of the SOFTWARE and/or its components that you are utilizing and may provide upgrades or supplements to the SOFTWARE that may be automatically downloaded to your INSTRUMENT.
- **Links to Third Party Sites.** The SOFTWARE may provide you with the ability to link to third party sites through the use of the SOFTWARE. The third party sites are not under the control of MS, Microsoft Corporation or their affiliates. Neither MS nor Microsoft Corporation nor their affiliates are responsible for (i) the contents of any third party sites, any links contained in third party sites, or any changes or updates to third party sites, or (ii) webcasting or any other form of transmission received from any third party sites. If the SOFTWARE provides links to third party sites, those links are provided to you only as a convenience, and the inclusion of any link does not imply an endorsement of the third party site by MS, Microsoft Corporation or their affiliates.
- **Additional Software/Services.** The SOFTWARE may permit [ADVANTEST], MS, Microsoft Corporation or their affiliates to provide or make available to you SOFTWARE updates, supplements, add-on components, or Internet-based services components of the SOFTWARE after the date you obtain your initial copy of the SOFTWARE ("Supplemental Components").
 - If [ADVANTEST] provides or makes available to you Supplemental Components and no other EULA terms are provided along with the Supplemental Components, then the terms of this EULA shall apply.
 - If MS, Microsoft Corporation or their affiliates make available Supplemental Components, and no other EULA terms are provided, then the terms of this EULA shall apply, except that the MS, Microsoft Corporation or affiliate entity providing the Supplemental Component(s) shall be the licensor of the Supplemental Component(s).

[ADVANTEST], MS, Microsoft Corporation and their affiliates reserve the right to discontinue any Internet-based services provided to you or made available to you through the use of the SOFTWARE.

This EULA does not grant you any rights to use the Windows Media Format Software Development Kit ("WMFSDK") components contained in the SOFTWARE to develop a software application that uses Windows Media technology. If you wish to use the WMFSDK to develop such an application, visit <http://msdn.microsoft.com/workshop/imedia/windowsmedia/sdk/wmsdk.asp>, accept a separate license for the WMFSDK, download the appropriate WMFSDK, and install it on your system.

3. SETUP

This chapter describes how to set up this instrument. Topics included in this chapter are:

- 3.1 Unpacking Inspection
- 3.2 Locating This Instrument
- 3.3 Connecting Accessories
- 3.4 Supply Description
- 3.5 Operation Check

3.1 Unpacking Inspection

When the product is delivered, check the condition of it and its accessories included by following these steps:

1. Check that the box and the padding in which the product was shipped has not been damaged during transit.

IMPORTANT: *If the box or the padding is damaged, leave them in their original condition until the inspection described below is complete.*

2. Check the product surfaces for any damage.

WARNING: *Do not supply any power to this instrument if the cover, panels (front and rear), LCD display, power switch, connector or any other key component are damaged. Electrical shocks may result from using damaged components.*

3. Referring to the standard accessory list of the OPT64 in Table 3-1, check that a standard accessory has been supplied and that no accessory is damaged.

Contact your dealer or Advantest in any of the following situations:

- The box or the padding in which the product was shipped was damaged during transit.
- The product surfaces are damaged.
- Any of the standard accessories are missing or damaged.
- Faults are detected in any subsequent product verification test.

Table 3-1 Standard Accessory

Name	Model	Quantity	Remarks
R3681 Series OPT64 User's Guide	ER3681OPT64	1	English version

3.2 Locating This Instrument

3.2 Locating This Instrument

This section describes the environment in which this instrument should be installed.

3.2.1 Operating Environment

This instrument should only be used in an environment that satisfies the following conditions:

- Ambient temperature: +5 °C to +40 °C (operating temperature)
-20 °C to +60 °C (Storage temperature range)
- Relative humidity: RH80% or less (no condensation)
- An area free from corrosive gas
- An area away from direct sunlight
- A area free from dust
- An area free from vibrations
- A low noise area

Although this instrument has been designed to withstand a certain amount of noise riding on the AC power line, it should be used in an area of low noise. Use a noise filter if ambient noise is unavoidable.

- An area allowing unobstructed airflow

There is an exhaust-cooling fan on the rear panel and exhaust vents on both sides and the bottom (toward the front) of this instrument. Do not block these vents. The resulting internal temperature rise will affect measurement accuracy. Keep the rear panel 10 centimeters away from the wall. In addition, do not attempt to use this instrument when it is standing on its rear panel or lying on either side.




Figure 3-1 Operating Environment

3.2.2 Prevention of Electrostatic Buildup

To prevent electrostatic discharge (ESD) from damaging components in this instrument, the precautions described below should be taken. We recommend that two or more countermeasures are combined to provide adequate protection from ESD.

(Static electricity can easily be generated when a person moves or an insulator is rubbed.)

Table 3-2 ESD Countermeasures

Operator	Use a wrist strap (see Figure 3-2).
Floor in the work area	Install a conductive mat, use conductive shoes, and connect both to ground (see Figure 3-3).
Workbench	Install a conductive mat and connect it to ground (see Figure 3-4).




Figure 3-2 Countermeasures against Static Electricity from the Human Body




Figure 3-3 Countermeasures against Static Electricity from the Work Floor

3.3 Connecting Accessories




Figure 3-4 Countermeasures against Static Electricity from the Workbench

3.3 Connecting Accessories

This section describes how to connect accessories to this instrument and run it.

3.3.1 Connecting the Keyboard and Mouse

Plug the keyboard and mouse into their respective front-panel connectors before turning on this instrument.




Figure 3-5 Connecting the Keyboard and Mouse

3.4 Supply Description

This section describes how to check the power supply specifications and connect the power cable.

3.4.1 Check the Supply Power

Table 3-3 summarizes the power supply specifications for this instrument. Make sure that the power supply available to this instrument meets these specifications.

Table 3-3 Power Supply Specifications

	100 V AC Operation	200 V AC Operation	Remarks
Input voltage range	90 V to 132 V	198 V to 250 V	Automatically switches between input levels of 100 V AC and 200 V AC.
Frequency range	47 Hz to 63 Hz		
Power consumption	450 VA or below		

WARNING: *Be sure to provide a power supply that meets the specified power supply specifications for this instrument. Failure to meet the specifications could cause damage to this instrument.*

3.4.2 Connecting the Power Cable

This instrument comes with a three-core power cable with a ground conductor. To prevent electrical shock hazards, ground this instrument by plugging the power cable into a three-pole power outlet.

1. Check the power cable included with this instrument for any damage.

WARNING: *Never use a damaged power cable. Electrical shock could result.*

2. Plug one end of the power cable included with this instrument into the AC power connector on this instrument rear panel and the other into a three-pin power outlet that has a ground pin (see Figure 3-6).

3.4.2 Connecting the Power Cable




Figure 3-6 Connecting the Power Cable

WARNING:

1. Use a power cable rated for the voltage being used. Be sure, however, to use a power cable that conforms to the safety standards of your country when using this instrument (Refer to "Safety Summary").
 2. Plug the power cable into a three-pin power outlet that has a ground pin to prevent electrical shocks. Using an extension cable that has no ground pin would negate having a ground.
-

3.5 Operation Check

This section describes how to make a simple operation check on this instrument by using its built-in autocalibration feature. To verify that this instrument runs correctly, follow these steps:

Starting up this instrument

1. Connect the power cable as instructed in 3.4.2 "Connecting the Power Cable."
2. Switch on the power breaker on the rear panel and wait for 3 seconds or more.
3. Press the **POWER** switch to switch on the power.




Figure 3-7 **POWER** Switch

CAUTION:

1. *If the power to this instrument is suddenly interrupted while the unit is in operation, such as is the power cable is disconnected, the hard disk drive could be damaged. Even if the hard disk drive does not fail, Scandisk launches to check for possible data corruption the next time this instrument starts up.*
2. *About Scandisk*
If this instrument has been switched off without being shut down, Scandisk will automatically launch to check for any corrupt data. Do not abort Scandisk while it is running. If Scandisk locates any corrupt data, take appropriate action by following the displayed messages. The software in this instrument resumes automatically when Scandisk ends.

-
4. The power-on diagnostic program launches to carry out self-diagnostics. The self-diagnostic program take about 1 minute to complete.
 5. The initial screen shown in Figure 3-8 is displayed unless this instrument is faulty. The initial screen may give look differently from Figure 3-8, depending on the settings in effect the last time this instrument was switched off.

NOTE: Refer to Chapter 8, "MAINTENANCE" of R3681 Series User's Guide if any error messages are displayed as a result of the self-diagnostic program.

3.5 Operation Check




Figure 3-8 Initial Setup Screen

Running autocalibration

6. <R3681>
Install this instrument as shown in Figure 3-9 by using the SMA (f)-SMA (f) adapter, SMA (m)-BNC (f) adapter, and input cable (A01261-30) that come with this instrument as standard.
<R3671>
Hook up this instrument as shown in Figure 3-9 by using the N (m)-BNC (f) adapter, and input cable (A01261-30) that come with this instrument as standard.




Figure 3-9 Autocalibration

IMPORTANT: Allow this instrument to warm up for at least 30 minutes before running the autocalibration. For more information on how to use the autocalibration, refer to Section 4.3.1, “Autocalibration” of the R3681 Series User's Guide.

7. Touch the [Cal] button on this instrument's menu bar to select [SA Cal] from the dropdown menu.
8. Autocalibration runs.
The autocalibration takes about 1 minute to complete.
9. Make sure that no error messages are displayed as a result of the autocalibration.

MEMO: Refer to Chapter 8, “MAINTENANCE” of the R3681 Series User's Guide if error messages are displayed as a result of the autocalibration.

Switching off power

Press **POWER** to switch off this instrument.

The final procedure is complete and the power is automatically turned off.

4. MEASUREMENT EXAMPLES

This chapter describes how to use this option by using specific measurement examples.

4.1 Modulation Accuracy Measurement of the QPSK Signal


Signal Specifications

Table 4-1 shows the signal specifications.

Table 4-1 Signal Specifications

Symbol rate	1 MHz
Modulation format	QPSK
Signal	Continuous wave
Transmission filter	Nyquist, roll-off factor: 0.5
Center frequency	2 GHz
Output level	-10 dBm

Connections



Note: The R3671 uses the N(m)-SMA(f) adapter.

Figure 4-1 Modulation Accuracy Measurement Connection Diagram

4.1 Modulation Accuracy Measurement of the QPSK Signal

Measurement condition settings

1. Touch **[Config]** on the menu bar and select **[Modulation Analyzer]**.
2. Touch **[Modulation]** on the menu bar and select **[Vector Modulation Analysis]**.
3. Touch the **{FREQ}** button on the function bar.
4. Touch the **Center** key on the soft menu bar.
5. Press **[2]** and **[G/p]** on the keypad.
The center frequency is set to 2 GHz.
6. Touch the **{TRIGGER}** button on the function bar.
7. Touch the **Trigger Source** key on the soft menu bar.
8. Touch the **Free Run** key on the soft menu bar.
The trigger source is set to the internal trigger.
9. Touch the **{INPUT}** button on the function bar.
10. Touch the **Input Setup** key on the soft menu bar.
The **[Input Setup]** dialog box is displayed.
11. Set **[Input]** in the **[Input Setup]** dialog box to **[RF]**.
12. Set the **[IQ Inverse]** option button in the **[Input Setup]** dialog box to **[OFF]**.




Figure 4-2 **[Input Setup]** Dialog Box

13. Touch the close button **✕** in the **[Input Setup]** dialog box to close the dialog box.
14. Touch the **{LEVEL}** button on the function bar.
15. Touch the **Auto Level Set** key on the soft menu bar.
The Ref Level is automatically set to the optimum value.
16. Touch the **{MEAS SETUP}** button on the function bar.
17. Touch the **Meas Parameters** key on the soft menu bar.
The **[Measurement Parameters Setup]** dialog box is displayed.
18. Touch the **[Symbol Rate]** text box and press **[1]** and **[M/n]** on the keypad.
19. Set **[Modulation Format]** to **[QPSK]**.

20. Set the **[Differential Code]** option button to **[OFF]**.
21. Touch the **[A/D Capture Length]** text box and press **[1]**, **[5]**, **[0]**, **[0]**, and **[ENT]** on the keypad.
22. Touch the **[Analysis Length]** text box and press **[1]**, **[5]**, **[0]**, **[0]**, and **[ENT]** on the keypad.
23. Set the **[Burst Search]** option button to **[OFF]**.
24. Set the **[Compensate Origin Offset]** option button to **[ON]**.
25. Set the **[EVM Calculation Method]** option button to **[RMS]**.




Figure 4-3 [Measurement Parameters Setup] Dialog Box

26. Touch the **[Return]** key on the soft menu bar to close the **[Measurement Parameters Setup]** dialog box.
27. Touch the **[Synchronous Parameters]** key on the soft menu bar.
The **[Synchronous Parameters Setup]** dialog box is displayed.
28. Set the **[Synchronization]** option button to **[OFF]**.

4.1 Modulation Accuracy Measurement of the QPSK Signal




Figure 4-4 [Synchronous Parameters Setup] Dialog Box

29. Touch the **Return** key on the soft menu bar to close the [Synchronous Parameters Setup] dialog box.
30. Touch the **Filter Parameters** key on the soft menu bar.
The [Filter Parameters Setup] dialog box is displayed.
31. Set [Filter Type] in [Meas Filter] to [Sinc].
32. Touch the [Filter Parameter] text box in [Meas Filter] and press **0**, **.**, **5**, and **ENT** on the keypad.
33. Touch the [Filter Tap] text box in [Meas Filter] and press **2**, **0**, and **ENT** on the keypad.
34. Set [Filter Type] in [Ref Filter] to [Nyquist].
35. Touch the [Filter Parameter] text box in [Ref Filter] and press **0**, **.**, **5**, and **ENT** on the keypad.
36. Touch the [Filter Tap] text box in [Ref Filter] and press **2**, **0**, and **ENT** on the keypad.

4.1 Modulation Accuracy Measurement of the QPSK Signal




Figure 4-5 [Filter Parameters Setup] Dialog Box

37. Touch the **Return** key on the soft menu bar to close the [Filter Parameters Setup] dialog box.
38. Press the **SINGLE** button on the front panel.

The Single measurement is performed and the measurement results are displayed.




Figure 4-6 Modulation Accuracy Measurement Results

4.2 EVM Measurement of the DUT by Using the Equalizing Filter

4.2 EVM Measurement of the DUT by Using the Equalizing Filter

By using the Equalizing Filter function, the signal source frequency characteristics are canceled and then EVM of the DUT such as an amplifier or filter can be measured. An example, which is measured by using the Equalizing Filter function, is shown below.




Figure 4-7 Connection Diagram using the Equalizing Filter

[Measurement condition settings]

1. Connect the instruments to the 1-3 path shown in Figure 4-7.
2. Touch **[Config]** on the menu bar and select **[Modulation Analyzer]**.
3. Touch **[Modulation]** on the menu bar and select **[Vector Modulation Analysis]**.
4. Touch the **{FREQ}** button on the function bar.
5. Touch the **Center** key on the soft menu bar.
6. Press **2** and **G/p** on the keypad.
The center frequency is set to 2 GHz.
7. Touch the **{TRIGGER}** button on the function bar.
8. Touch the **Trigger Source** key on the soft menu bar.
9. Touch the **Free Run** key on the soft menu bar.
The trigger source is set to the internal trigger.
10. Touch the **{INPUT}** button on the function bar.
11. Touch the **Input Setup** key on the soft menu bar.
The **[Input Setup]** dialog box is displayed.

12. Set **[Input]** in the **[Input Setup]** dialog box to **[RF]**.
13. Set the **[IQ Inverse]** option button in the **[Input Setup]** dialog box to **[OFF]**.




Figure 4-8 **[Input Setup]** Dialog Box

14. Touch the close button **X** in the **[Input Setup]** dialog box to close the dialog box.
15. Touch the **{LEVEL}** button on the function bar.
16. Touch the **Auto Level Set** key on the soft menu bar.
The Ref Level is automatically set to the optimum value.
17. Touch the **{MEAS SETUP}** button on the function bar.
18. Touch the **Meas Parameters** key on the soft menu bar.
The **[Measurement Parameters Setup]** dialog box is displayed.
19. Touch the **[Symbol Rate]** text box and press **1** and **M/n** on the keypad.
20. Set **[Modulation Format]** to **[QPSK]**.
21. Set the **[Differential Code]** option button to **[OFF]**.
22. Touch the **[A/D Capture Length]** text box and press **1**, **5**, **0**, **0**, and **ENT** on the keypad.
23. Touch the **[Analysis Length]** text box and press **1**, **5**, **0**, **0**, and **ENT** on the keypad.
24. Set the **[Burst Search]** option button to **[OFF]**.
25. Set the **[Compensate Origin Offset]** option button to **[ON]**.
26. Set the **[EVM Calculation Method]** option button to **[RMS]**.

4.2 EVM Measurement of the DUT by Using the Equalizing Filter




Figure 4-9 [Measurement Parameters Setup] Dialog Box

27. Touch the **Return** key on the soft menu bar to close the **[Measurement Parameters Setup]** dialog box.
28. Touch the **Synchronous Parameters** key on the soft menu bar. The **[Synchronous Parameters Setup]** dialog box is displayed.
29. Set the **[Synchronization]** option button to **[OFF]**.




Figure 4-10 [Synchronous Parameters Setup] Dialog Box

30. Touch the **Return** key on the soft menu bar to close the **[Synchronous Parameters Setup]** dialog box.
31. Touch the **Filter Parameters** key on the soft menu bar. The **[Filter Parameters Setup]** dialog box is displayed.
32. Set **[Filter Type]** in **[Meas Filter]** to **[Sinc]**.

33. Touch the **[Filter Parameter]** text box in **[Meas Filter]** and press **[0]**, **[.]**, **[5]**, and **[ENT]** on the keypad.
34. Touch the **[Filter Tap]** text box in **[Meas Filter]** and press **[2]**, **[0]**, and **[ENT]** on the keypad.
35. Set **[Filter Type]** in **[Ref Filter]** to **[Nyquist]**.
36. Touch the **[Filter Parameter]** text box in **[Ref Filter]** and press **[0]**, **[.]**, **[5]**, and **[ENT]** on the keypad.
37. Touch the **[Filter Tap]** text box in **[Ref Filter]** and press **[2]**, **[0]**, and **[ENT]** on the keypad.




Figure 4-11 **[Filter Parameters Setup]** Dialog Box

38. Touch the **[Return]** key on the soft menu bar to close the **[Filter Parameters Setup]** dialog box.
39. Press the **[SINGLE]** button on the front panel.
The Single measurement is performed and the measurement results are displayed.

4.2 EVM Measurement of the DUT by Using the Equalizing Filter




Figure 4-12 Modulation Accuracy Measurement Results

40. Touch the {MEAS SETUP} button on the function bar.
41. Touch the **Make Equalizer** key on the soft menu bar.
The Equalizing Filter coefficient is created.
42. Touch the {DISPLAY} button on the function bar.
43. Touch the active window switching icon on the measurement tool bar.
44. Touch [Window2] to activate [Window2].
45. Touch the **Window Format** key on the soft menu bar.
The [Window Format] dialog box is displayed.
46. Select [Transmission Mag Characteristics].
47. Touch [Window4] to activate [Window4].
48. Select [Transmission Phase Characteristics].
49. Touch the **Return** key on the soft menu bar to close the [Window Format] dialog box.
50. Touch [Window2] to activate [Window2].
51. Touch the {SCALE} button on the function bar.
52. Touch the **Auto Scale** key on the soft menu bar.
The horizontal-axis and vertical-axis are automatically adjusted to the optimum scale.
53. Touch [Window4] to activate [Window4].

4.2 EVM Measurement of the DUT by Using the Equalizing Filter

54. Touch the **Auto Scale** key on the soft menu bar.
55. Check the transfer characteristics.




Figure 4-13 Transfer Characteristics Measurement Results

56. Connect the instruments to the 2-4 path shown in Figure 4-7.
57. Touch the **{MEAS SETUP}** button on the function bar.
58. Touch the **Equalizing Filter** key on the soft menu bar.
Equalizing Filter is set to ON and the mode, which uses the Equalizing Filter, is set.
59. Touch the **{LEVEL}** button on the function bar.
60. Touch the **Auto Level Set** key on the soft menu bar.
Ref Level is automatically set to the optimum value.

4.2 EVM Measurement of the DUT by Using the Equalizing Filter

61. Press the **SINGLE** button on the front panel.

The Single measurement is performed, and the DUT measurement results corrected by the equalizing process are displayed.





Figure 4-14 DUT Measurement Results

5. MENU MAP, FUNCTIONAL EXPLANATION

This chapter describes the configurations and functions of the soft keys displayed on the touch screen of the single-carrier general-purpose modulation analysis option.

MEMO:

- [.....] *Used to enclose a menu name, key name, item name in the dialog box, button name, or the name of selected items in lists and menus.*
- {...} *Shows a function button on the function bar.*
-  *Shows a soft key on the soft menu bar.*
- *A dialog box is surrounded by a broken line.*
- *Operations are supposed to be made through the touch screen and “touch” means to press a button or a key.*

5.1 Menu Index


Operation Key	Pages	Operation Key	Pages
[A/D Capture Length]	5-4, 5-5	[Modulation Format]	5-4, 5-5
[Amplitude Synchronization]	5-4, 5-6	[Phase Error Spectrum]	5-10
[Analysis Length]	5-4, 5-5	[Phase Error vs Symbol]	5-10
[Analysis Start Offset]	5-4, 5-6	[Phase vs Symbol]	5-10, 5-11
[Baseband Input]	5-15	[Power Spectrum]	5-10
[Burst Search]	5-4, 5-5	[Power vs Symbol]	5-10
[Compensate Origin Offset]	5-4, 5-6	[Q Eye Diagram]	5-10, 5-11
[Constellation]	5-10, 5-11, 5-12	[Ref Filter]	5-4, 5-7
[Demodulated Data]	5-10, 5-11	[Search Threshold]	5-4, 5-5
[Differential Code]	5-4, 5-5	[Symbol]	5-10, 5-12
[EVM Calculation Method]	5-4, 5-6	[Symbol Rate]	5-4, 5-5
[EVM Spectrum]	5-10	[Synchronization]	5-4, 5-6
[EVM vs Symbol]	5-10	[Synchronous Length]	5-4, 5-6
[Filter Parameter]	5-4, 5-7	[Synchronous Offset]	5-4, 5-6
[Filter Tap]	5-4, 5-7	[Synchronous Word]	5-4, 5-6
[Filter Type]	5-4, 5-6, 5-7	[Total Result]	5-10, 5-11
[Frequency Eye Diagram]	5-10, 5-11	[Trace]	5-10, 5-12
[Frequency vs Symbol]	5-10, 5-11	[Trace & Symbol]	5-10, 5-12
[I Eye Diagram]	5-10, 5-11	[Transmission Mag Characteristics]	5-10, 5-12
[Input]	5-15	[Transmission Phase Characteristics]	5-10, 5-12
[IQ Inverse]	5-15	[User Filter Tap]	5-4, 5-7
[Linc]	5-10, 5-12	[vs Symbol Graph]	5-10, 5-12
[Load File]	5-4, 5-6, 5-7	{DISPLAY}	5-10
[Load Meas Filter]	5-4, 5-6	{FREQ}	5-18
[Load Ref Filter]	5-4, 5-7	{INPUT}	5-15
[Mag Error Spectrum]	5-10	{LEVEL}	5-17
[Mag Error vs Symbol]	5-10	{MEAS MODE}	5-4
[Meas Filter]	5-4, 5-6	{MKR}	5-14
		{SCALE}	5-13
		{TRIGGER}	5-16
		Analysis Restart	5-4, 5-5

5.1 Menu Index

ATT	5-17	Trigger Slope	5-16
Auto Level Set	5-17	Trigger Source	5-16
Auto Scale	5-13	Window Format	5-10
Average	5-4, 5-8	X Scale Left	5-13
Average Peak Type	5-4, 5-8	X Scale Right	5-13
Average times	5-4, 5-8	Y Scale Lower	5-13
Bluetooth	5-4, 5-8	Y Scale Upper	5-13
CDPD	5-4, 5-8		
Center	5-18		
Channel Number	5-18		
DECT	5-4, 5-8		
Delta Marker	5-14		
Display Type	5-10, 5-12		
Dual Display	5-10, 5-12		
DVB-C	5-4, 5-8		
Equalizing Filter	5-4, 5-9		
Ext1	5-16		
Ext2	5-16		
Filter Parameters	5-4, 5-6		
Free Run	5-16		
Freq Offset	5-18		
GSM	5-4, 5-7		
IF Power	5-16		
Input Setup	5-15		
Link	5-16		
Make Equalizer	5-4, 5-8		
Marker	5-14		
Marker Interlock	5-14		
Marker OFF	5-14		
Meas Parameters	5-4, 5-5		
Min ATT	5-17		
PDC	5-4, 5-7		
Peak Search	5-14		
PHS	5-4, 5-8		
Preamp On/Off	5-17		
Quad Display	5-10, 5-12		
Ref Level	5-17		
Ref Offset	5-17		
Refresh Cycle	5-4, 5-8		
Return	5-4, 5-6, 5-7, 5-8, 5-12, 5-16		
Save Demod Data	5-10, 5-12		
Scale Interlock	5-13		
Single Display	5-10, 5-12		
Standard	5-4, 5-7		
Symbol Start	5-13		
Symbol Stop	5-13		
Synchronous Parameters	5-4, 5-6		
TETRA	5-4, 5-8		
Trigger Delay	5-16		

5.2 Switching Communication Systems

The menu bar of this option is arranged as follows:



The menu bar consists of the same items as those of Spectrum Analyzer.

Select **[Modulation Analyzer]** from **[Config]** on the menu bar to select a modulation analysis function.

Select **[Vector Modulation Analysis]** from **[Modulation]** on the menu bar to select the single-carrier general-purpose modulation analysis function.

5.3 Function Bar

This section describes the functions of each function button displayed on the function bar. The configuration of the function buttons of this option is as follows:



If you touch a button on the function bar, the relevant soft keys are displayed on the soft menu bar.

5.4 Soft Menu Bar

The area located on the right-hand side of the screen and in which soft keys are displayed is called the soft menu bar.

If you touch a button on the function bar, the relevant soft keys are displayed on the soft menu bar.

5.5 Description of the Function of Each Key


5.5 Description of the Function of Each Key

This section describes the function of each key.

5.5.1 {MEAS SETUP}

If {MEAS SETUP} is touched, soft keys, which relate to analysis parameter settings, are displayed on the soft menu bar.

{MEAS SETUP}



Measurement Parameters Setup

- [Symbol Rate]
- [Modulation Format]
- [Differential Code]
- [A/D Capture Length]
- [Analysis Length]
- [Burst Search]
- [Search Threshold]
- [Amplitude Synchronization]
- [Analysis Start Offset]
- [Compensate Origin Offset]
- [EVM Calculation Method]

Synchronous Parameters Setup

- [Synchronization]
- [Synchronous Word]
- [Synchronous Length]
- [Synchronous Offset]

Filter Parameters Setup

- [Meas Filter]
 - [Filter Type]
 - [Load Meas Filter]
 - [Load File]
 - [Filter Parameter]
 - [Filter Tap]
 - [User Filter Tap]
- [Ref Filter]
 - [Filter Type]
 - [Load Ref Filter]
 - [Load File]
 - [Filter Parameter]
 - [Filter Tap]
 - [User Filter Tap]

Standard

- PDC
- GSM
- PHS
- DECT
- CDPD
- TETRA
- DVB-C
- Bluetooth
- Return

Average

- Average times
- Average Peak Type
- Refresh Cycle

Analysis Restart

The measurement of AD data, which has already been acquired, restarts by touching the **Analysis Restart** key.

MEMO: Even if Average is set to ON, the analysis is performed without Average.

Meas Parameters

The dialog box, which is used to set the measurement conditions, is displayed by touching the **Meas Parameters** key.

[Symbol Rate]

Sets the symbol rate of the signal.
The setting range is 10 kHz to 20 MHz and the setting resolution is 10 Hz.

MEMO: A symbol rate of 270833 Hz can be set to perform the GSM analysis. Set the symbol rate of hardware to 1625/6 kHz and perform the analysis after setting the symbol rate to 270833 Hz.

[Modulation Format]

Selects the modulation format of the signal.

[Differential Code]

Sets whether the modulation format of the signal is Differential Code. This parameter cannot be set when Modulation Format is set to $\pi/4$ DQPSK.

[A/D Capture Length]

Sets the number of symbols of A/D data acquired into memory.

MEMO: Lower limit of the setting
BPSK, QPSK, $\pi/4$ DQPSK, 8PSK, FSK,
MSK: 100, 16QAM: 300, 32QAM: 320,
64QAM: 600, 128QAM: 1000, 256QAM: 1200

Upper limit of the setting
Except for FSK: 50000, FSK: 25000

[Analysis Length]

Set the number of symbols to be analyzed.

MEMO: Lower limit of the setting
BPSK, QPSK, $\pi/4$ DQPSK, 8PSK, FSK,
MSK: 100, 16QAM: 300, 32QAM: 320,
64QAM: 600, 128QAM: 1000, 256QAM: 1200

Upper limit of the setting
Except for FSK: 10000, FSK: 5000

[Burst Search]

Sets whether to search for the burst in the acquired data by software.

ON: Searches for the burst by software.

OFF: Does not search for the burst by software.

[Search Threshold]

Sets the threshold that is used when the software searches for the burst. This parameter cannot be set when Burst Search is set to OFF.

5.5.1 {MEAS SETUP}

- [Amplitude Synchronization]** Sets whether to synchronize with amplitude when searching for the burst. This parameter cannot be set when Burst Search is set to OFF.
 ON: Synchronizes with amplitude.
 OFF: Does not synchronize with amplitude.
- [Analysis Start Offset]** Specifies the number of offset symbols of the analysis start point against the rising edge of the burst when the burst signal is measured. This parameter cannot be set when Burst Search is set to OFF or Amplitude Synchronization is set to ON.
- [Compensate Origin Offset]** Sets whether to compensate the origin offset when the modulation accuracy is calculated.
 ON: Compensates the origin offset.
 OFF: Does not compensate the origin offset.
- [EVM Calculation Method]** Sets the calculation method of the reference level when the modulation accuracy is calculated.
 RMS: Sets the reference level to the RMS value of the amplitude of the ideal signal.
 Max: Sets the reference level to the maximum value of the amplitude of the ideal signal.

Return When the **Return** key is touched, the dialog box closes and the soft key array on the soft menu bar returns to the previous menu.

Synchronous Parameters The dialog box, which is used to set the synchronous conditions, is displayed by touching the **Synchronous Parameters** key.

- [Synchronization]** Sets whether to perform a measurement synchronized with Sync Word.
- [Synchronous Word]** Sets the user-defined Sync Word. This parameter cannot be set when Synchronize is set to OFF.
- [Synchronous Length]** Sets the bit length of Sync Word. The setting resolution is the number of bits per symbol in the modulation format set in **[Modulation Format]**. This parameter cannot be set when Synchronize is set to OFF.
- [Synchronous Offset]** Sets the number of offset symbols of Sync Word. This parameter cannot be set when Synchronize is set to OFF.

Return When the **Return** key is touched, the dialog box closes and the soft key array on the soft menu bar returns to the previous menu.

Filter Parameters The dialog box, which is used to set the receiving filter and the reference filter, is displayed by touching the **Filter Parameters** key.

- [Meas Filter]** Set the receiving filter.
- [Filter Type]** Set the type of the receiving filter.
- [Load Meas Filter]** Loads the user filter. The user filter can be loaded only when Filter Type is set to User.
- [Load File]** Displays the file name of the user filter to be loaded.

[Filter Parameter]	Sets the filter parameter. Filter Parameter cannot be set when Filter Type is set to User.
	<i>MEMO: In Filter Parameter, the roll-off is set when Filter Type is set to Nyquist or Root Nyquist, BT is set when Filter Type is set to Gauss, and the cutoff ratio to the oversampling (FSK: 8, except for FSK: 4) is set when Filter Type is set to Sinc.</i>
[Filter Tap]	Sets the number of taps of the filter in units of symbol. This parameter cannot be set when Filter Type is set to User.
[User Filter Tap]	Displays the number of taps of the user filter to be loaded.
[Ref Filter]	Sets the reference filter.
	<i>MEMO: Set the reference filter correctly when Modulation Format is set to FSK or MSK. Inaccurate measurements may be performed.</i>
[Filter Type]	Set the type of the reference filter.
	<i>MEMO: When Modulation Format is set to any format except for FSK and MSK, the signal is interpolated by Dirac Pulse and then filtered by the reference filter. When Modulation Format is set to FSK or MSK, the phase is interpolated by Rectangular and then filtered by the reference filter.</i>
[Load Ref Filter]	Loads the user filter. The user filter can be loaded only when Filter Type is set to User.
[Load File]	Displays the file name of the user filter to be loaded.
[Filter Parameter]	Sets the filter parameter. This parameter cannot be set when Filter Type is set to User or Rect.
	<i>MEMO: In Filter Parameter, the roll-off is set when Filter Type is set to Nyquist or Root Nyquist and BT is set when Filter Type is set to Gauss.</i>
[Filter Tap]	Sets the number of taps of the filter in units of symbol. This parameter cannot be set when Filter Type is set to User or Rect.
[User Filter Tap]	Displays the number of taps of the user filter to be loaded.
Return	When the Return key is touched, the dialog box closes and the soft key array on the soft menu bar returns to the previous menu.
Standard	If the Standard key is touched, the standards are displayed on the soft menu bar.
PDC	Sets Meas Parameters and Filter Parameters to the PDC measurement conditions.
GSM	Sets Meas Parameters and Filter Parameters to the GSM measurement conditions.

5.5.1 {MEAS SETUP}

PHS	Sets Meas Parameters and Filter Parameters to the PHS measurement conditions.
DECT	Sets Meas Parameters and Filter Parameters to the DECT measurement conditions.
CDPD	Sets Meas Parameters and Filter Parameters to the CDPD measurement conditions.
TETRA	Sets Meas Parameters and Filter Parameters to the TETRA measurement conditions.
DVB-C	Sets Meas Parameters and Filter Parameters to the DVB-C measurement conditions.
Bluetooth	Sets Meas Parameters and Filter Parameters to the Bluetooth measurement conditions.
Return	When the Return key is touched, the soft key array on the soft menu bar returns to the previous menu.
Average	If the Average key is touched, the setting menu in the average measurement is displayed on the soft menu bar.
Average times	Sets Average to ON or OFF. If Average is set to ON, the dialog box used to set the number of times that averaging is performed is displayed.
Average Peak Type	Sets how to calculate the Peak value in the Average measurement. Calculates the Peak value in all measurements when Average Peak Type is set to Hold. Averages the Peak value of each measurement when Average Peak Type is set to Avg. This parameter cannot be set when Average times is set to OFF.
<hr/>	
	<i>MEMO: Absolute values of Peak Phase Error and Peak Mag Error are displayed when Average Peak Type is set to Avg.</i>
<hr/>	
Refresh Cycle	Sets the number of refresh cycles of the measurement result in the Average measurement. Refreshes the measurement result every set number of times averaging is performed. This parameter cannot be set when Average times is set to OFF.
<hr/>	
	<i>MEMO: The measurement result continues to refresh after Average has been completed.</i>
<hr/>	
Return	When the Return key is touched, the soft key array on the soft menu bar returns to the previous menu.
Make Equalizer	The Equalizing filter is created by touching the Make Equalizer key. If no measurement is performed after hardware settings are changed, the Equalizing filter cannot be created. The Equalizing filter cannot be created when Modulation Format is set to FSK.
<hr/>	
	<i>MEMO: After Analysis Length is set to 300 or more and the measurement is performed, the Equalizing filter can be created.</i>
<hr/>	


Equalizing Filter

Sets Equalizing Filter to ON or OFF. This parameter cannot be set before Equalizing Filter is created.

5.5.2 {DISPLAY}

5.5.2 {DISPLAY}

If the {DISPLAY} button is touched, soft keys, which relate to the active window format, active window display type, the number of divided windows, and demodulation data saving, are displayed on the soft menu bar.



Window Format

- | | |
|-------------------------|---|
| [Power vs Symbol] | The dialog box, which is used to set the display data, is displayed by touching the Window Format key. |
| [Power Spectrum] | Displays the power for each symbol on a graph. |
| [EVM vs Symbol] | Displays the power spectrum on a graph. |
| [EVM Spectrum] | Displays EVM for each symbol on a graph. |
| [Mag Error vs Symbol] | Displays the EVM spectrum on a graph. |
| [Mag Error Spectrum] | Displays the magnitude error for each symbol on a graph. |
| [Phase Error vs Symbol] | Displays the magnitude error spectrum on a graph. |
| [Phase Error Spectrum] | Displays the phase error for each symbol on a graph. |
| | Displays the phase error spectrum on a graph. |

MEMO: EVM vs Symbol, EVM Spectrum, Mag Error vs Symbol, Mag Error Spectrum, Phase Error vs Symbol, and Phase Error Spectrum are enabled when Modulation is set to any modulation format except for FSK.

[Phase vs Symbol]	Displays the phase for each symbol on a graph.
[Constellation]	Displays the constellation.
[Frequency vs Symbol]	Displays the frequency for each symbol on a graph.
[Frequency Eye Diagram]	Displays the frequency on an EYE diagram.
[I Eye Diagram]	Displays the I signal on an EYE diagram.
[Q Eye Diagram]	Displays the Q signal on an EYE diagram.
[Demodulated Data]	Displays the demodulated data from the LSB in units of symbol.
[Total Result]	Displays the numerical results.
	Except for FSK
Freq Error	Carrier frequency error
Frequency	Carrier frequency
Tx Power	Power through a receiving filter
Peak Power	Peak power through a receiving filter
Peak Factor	Ratio between Tx Power and Peak Power
EVM	Error vector magnitude
Mag Error	Magnitude error
Phase Error	Phase error
IQ Org Offset	Origin offset
Amp Droop	Amplitude droop
IQ Imbalance	IQ magnitude imbalance
Orthogonal Err	IQ orthogonal error
IQ Skew	IQ skew
SymRate Error	Symbol rate error

MEMO: IQ Imbalance, Orthogonal Err, IQ Skew, and SymRate Error can be analyzed when Modulation Format is set to any modulation format except for BPSK and MSK, and Filter Type of Ref Filter is set to any filter type except for Rect.

FSK

Freq Error	Carrier frequency error
Frequency	Carrier frequency
Tx Power	Power through the receiving filter
Peak Power	Peak power through the receiving filter

5.5.2 {DISPLAY}

Peak Factor	Ratio between Tx Power and Peak Power
IQ Org Offset	Origin offset
Amp Droop	Amplitude droop
Max Deviation	Maximum frequency deviation
Min Deviation	Minimum frequency deviation
Min/Max Deviation	Ratio between Max Deviation and Min Deviation

[Transmission Mag Characteristics]

Displays the magnitude transfer characteristics of the transmitter on a graph.

[Transmission Phase Characteristics]

Displays the phase transfer characteristics of the transmitter on a graph.

MEMO: Transmission Mag Characteristics and Transmission Phase Characteristics are enabled after Equalizing Filter is created.

Return

When the **Return** key is touched, the dialog box closes and the soft key array on the soft menu bar returns to the previous menu.

Display Type

The dialog box, which is used to set the display type, is displayed by touching the **Display Type** key.

[vs Symbol Graph]

Sets the display type of the symbol-axis graph.

[Trace & Symbol]

Displays both symbol points and their loci.

[Symbol]

Displays symbol points only.

[Trace]

Displays loci only.

[Constellation]

Sets the constellation display type.

[Trace & Symbol]

Displays both symbol points and their loci.

[Symbol]

Displays symbol points only.

[Line]

Displays symbol points which are connected by straight line.

Return

When the **Return** key is touched, the dialog box closes and the soft key array on the soft menu bar returns to the previous menu.

Single Display

Zooms into the window set to the active display when the display is split into quarters.

Dual Display

Zooms into the window set to the active display and the following window when the display is split into quarters.

Quad Display


Splits the display into quarters.

Save Demod Data

Saves the demodulated data.

5.5.3 {SCALE}

If the {SCALE} button is touched, soft keys, which relate to the Symbol-axis, X-axis, and Y-axis scale settings on the active window, are displayed on the soft menu bar.



Auto Scale

Sets the horizontal axis and vertical axis automatically.

Scale Interlock

Synchronizes the scale with the Symbol-axis on the displayed graph.

Symbol Start

Sets the minimum value on the Symbol-axis.

Symbol Stop

Sets the maximum value on the Symbol-axis.

X Scale Left

Sets the minimum value on the X-axis.

X Scale Right

Sets the maximum value on the X-axis.

Y Scale Upper

Sets the maximum value on the Y-axis.


Y Scale Lower

Sets the minimum value on the Y-axis.

5.5.4 {MKR}

5.5.4 {MKR}

If you touch the {MKR} button, the soft keys related to the marker setup are displayed on the side menu bar. Functions, which are enabled, depend on the type of the graph in an active window. If a window except for graph is active or if no graph data is given because the measurement has not been performed, these functions are unavailable.



Marker

Sets the X-axis position of the normal marker.

Delta Marker

Switches the delta marker display function ON and OFF.

ON: Displays a delta marker at the same position as a normal marker. Displays the relative value between a delta marker and a normal marker (measurement value such as EVM) in the marker area.

OFF: Hides a delta marker display.

Peak Search

Performs a peak search.

Marker Interlock


Synchronizes with the Symbol-axis marker on the displayed graph.

Marker OFF

Hides marker display.

5.5.5 {INPUT}

If the {INPUT} key is touched, the soft keys related to the setup of the input format to the instrument are displayed on the soft menu bar.



Input Setup

If you touch the **Input Setup** key, the dialog box used to set the input format to the instrument appears. Set the input format in accordance with the measured signal.

[Input]

Sets the input path of the signal.

RF: Sets the input path to the RF signal input.

Baseband(I&Q):

Sets the input path to the IQ signal (baseband) input.

[Baseband Input]

Sets the coupling when the IQ signal is input.

AC: Selects the AC coupling.

DC: Selects the DC coupling.

[IQ Inverse]

Selects whether to invert the phase of the measured signal.


ON: Inverts.

OFF: Does not invert.

5.5.6 {TRIGGER}

5.5.6 {TRIGGER}

If the {TRIGGER} button is touched, the soft keys related to the trigger setup are displayed on the soft menu bar.



Trigger Source

If the **Trigger Source** key is touched, the soft keys related to the trigger setup are displayed on the soft menu bar.

Free Run

Acquires data according to the internal timing of the instrument and analyzes.

IF Power

Acquires data in synchronization with the IF signal and analyzes.

Ext1

Acquires data in synchronization with the external signal entered into the EXT TRIG IN 1 connector and analyzes. The threshold level for Ext1 is fixed to the TTL level.

Ext2

Acquires data in synchronization with the external signal entered into the EXT TRIG IN 2 connector and analyzes. The threshold level for Ext2 can be set.

Link

Acquires data in synchronization with the trigger of an optional function and analyzes.

MEMO: For information on how to use the link trigger, refer to the manual of the option in which the link trigger is used.

Return

Returns to the previous soft key array on the soft menu bar.

Trigger Slope

Switches the trigger slope polarity + and -.

Available only for IF Power, Ext1, Ext2, and Link.

+: Starts the sweep at the rising edge of a trigger.


-: Starts the sweep at the falling edge of a trigger.

Trigger Delay

Sets the delay time from a trigger point. When analyzing, the start position of AD data acquisition is shifted to the delay time. This setting is enabled only when Trigger Source is set to IF Power, Ext1, Ext2, and Link.

5.5.7 {LEVEL}

If the {LEVEL} button is touched, the soft keys related to the setup of the attenuator and reference level are displayed on the soft menu bar.



Auto Level Set

Sets the reference level to the optimum value according to the measured signal. When the key is pressed, Auto Level Set is executed.

IMPORTANT: While Auto Level Set is being executed, the level of the measured signal must remain constant. Auto Level Set is executed for data acquisition time which depends on Symbol Rate and A/D Capture Length. When Symbol Rate is set to 10 kHz and A/D Capture Length is set to 50000, Auto Level Set acquires data for five seconds every time ATT is changed. If the reference level changes a lot, it takes a long time to complete Auto Level Set.

Ref Level

Sets the reference level.

ATT

Sets the attenuator.

Auto: Automatically sets the attenuator value based on the reference level.

Man: Sets the attenuator value.

Min ATT

Sets the Min ATT function to ON or OFF.

On: Sets the minimum attenuator value and restricts the attenuator regardless of whether ATT is Auto or Manual.

Off: Cancels the Min ATT restriction.

Preamp On/Off

Sets the preamplifier function to ON or OFF.

Ref Offset

Switches the reference level offset function ON and OFF.


On: Sets the offset value and changes only the display of the reference level by the offset value.
(Displayed reference level = Set value + Offset value)

Off: Cancels the offset function.

5.5.8 {FREQ}

5.5.8 {FREQ}

If the {FREQ} button is touched, the soft keys related to the measurement frequency setup are displayed on the soft menu bar.



Center

Sets the center frequency of the measured signal.

IMPORTANT: *Set the center frequency correctly. If it is set incorrectly, an error may occur in the center frequency error measurement and the measurement may be incorrect.*

Channel Number

If the channel number is set, the center frequency is automatically set by using the following formula.

$$(\text{Center frequency}) = (\text{Channel interval}) \times (\text{Channel number} + \text{Channel offset}) + (\text{Start frequency})$$

The parameters such as the channel interval, and the channel number setting range depend on the Standard selected by [Special]→[STD...]. For more information, refer to the R3681 Series User's Guide.

Freq Offset

Switches the center frequency offset function ON and OFF.

On: Sets the offset value and changes only the display of the center frequency by the offset value.
(Displayed center frequency = Set value + Offset value)

Off: Cancels the offset function.

5.5.9 Measurement Tool Bar


Functions such as waveform range selection and active window selection are displayed as icons.

The following functions can be used by touching the icons.



:Active window switching icon

Used to make one of the split windows active.



:Range specification icon (X-axis mode)

Used to specify a range in the window in which the waveform is displayed. After touching the icon, touch both sides of the range to be specified.



:Range specification icon (range mode)

Used to specify a range in the window in which the waveform is displayed. After touching the icon, touch the upper left corner and the lower right corner of the range to be specified.



:Peak search icon

Used to place a marker on the peak after searching for the peak of the waveform.



:Zoom in icon

Used to zoom in on the waveform displayed in the window. If you touch this icon after specifying the range by using the range specification icon, the range zooms in.



:Zoom out icon

Used to zoom out from the waveform displayed in the window.



:Range shift icon

Used to scroll the display without changing the scale.

6. SCPI COMMAND REFERENCE

This chapter describes the SCPI command reference for this instrument.

6.1 Command Reference Format

This section describes the format and layout used to describe commands in this chapter.

Each description includes the following items:

Function description

SCPI command

Parameter

Query reply

- |Function description|

The usage of commands and operations in this instrument.

- |SCPI command|

The SCPI command displays the syntax of a command sent from the external controller to this instrument. The syntax consists of a command and a number of parameters. The command and the parameters are separated by a space.

If a command has multiple parameters, they are separated by commas (.). The three points (...) displayed between commas represent the parameter(s) omitted at that position.

For example, the description <numeric value 1>, ..., <numeric value 4> shows that four parameters, <numeric value 1>, <numeric value 2>, <numeric value 3>, and <numeric value 4>, are required.

If the parameter is a character string type such as <character string>, <character string 1>, the parameter must be enclosed in double quotation marks (" "). If the parameter is <block>, it shows the block format data.

Text written in lowercase alphabetic characters in the syntax can be omitted.

For example, ":CALibration:CABLe" can be abbreviated to ":CAL:CABL."

The marks used in the syntax are defined as follows:

< >: Shows a parameter required for sending a command

| |: Shows that the command is optional
It can be omitted

{ }: Shows that only one item is required to be selected from multiple items

|: Used as a delimiter for multiple items written in curly brackets {..}

<ch>: Written in the command header and shows the target input channel number of the command
The channel number can be omitted. However, when it is written, channel number 1 is selected

<screen>: Written in the command header and shows the target screen number of the command
The screen number can be omitted. However, when it is written, a value from 1 to 4 can be selected
[{ 1 | 2 | 3 | 4 }]

6.1 Command Reference Format

For example, If the syntax below is specified, :CALC:CORR:EDEL:TIME 0.1 and :CALCULATE1:SELECTED:CORR:EDEL:TIME 25E-3 are valid.

Syntax: CALCulate{[1][2][3][4]}:SELEcted]:CORRection:EDELay:TIME <numeric value>

- [Parameter]

Describes a parameter required for sending a command.

If the parameter is numeric type or alphabetic, it is enclosed in angle brackets (<>).

If the parameter is optional, it is enclosed in curly brackets ({}).

In this manual, parameter types are described in the following formats:

< int >: A numeric value that can be input in the format NR1, NR2, or NR3 and rounded to an integer in this instrument

< real >: A numeric value that can be input in the format NR1, NR2, or NR3 and rounded to a valid-digit real number in this instrument

< bool >: Either OFF or ON can be entered.

< str >: A character string enclosed in quotation (‘ ’) or double quotation (“ ”) marks.

<block>: Block data type
The data content is an 8-bit binary data array

< type >: Character data selected from multiple types

- [Query reply]

When there is a query reply to the command, the data format used for reading the query is described.

Each parameter to be read is enclosed in curly brackets ({}). If multiple items, which are delimited by a vertical bar (|), exist in curly brackets ({}), only one of those items is read out. If parameters are delimited by commas (,) multiple parameters can be read out. The three points (...) displayed between commas represent data omitted from that position. For example, the description {numeric value 1}...., {numeric value 4} shows that four parameters {numeric value 1}, {numeric value 2}, {numeric value 3}, and {numeric value 4} are read.

If the parameter to be read is enclosed in square brackets ([]), the parameter may be omitted, depending on the measurement result, etc.

If the parameter to be read is a value in a unit, a description such as “Unit: dBm” is added to display the unit of the parameter value. However, only when the parameter is described in a level unit “dBm”, the level unit selected at that time will be applied to the parameter.

6.2 Common Commands

This section describes common IEEE commands.

Function description	SCPI Command	Parameter	Query reply	Remarks
Clears the status byte and related data	*CLS	-	-	
Macro definition for GET	*DDT	<block>	<block>	*1
Sets the standard event status enable register	*ESE	<int>	<int>	
Reads the standard event status register	*ESR?	-	<int>	
Device inquiry	*IDN?	-	<str>	*2
Notifies when all running operations are complete	*OPC	-	1	
Loads the device settings	*RCL	<int> POFF	-	*3
Resets the device	*RST	-	-	
Saves the device settings	*SAV	<int>	<int>	
Sets the service request enable register	*SRE	<int>	<int>	
Reads the status byte register	*STB?	-	<int>	
Triggers the device	*TRG	-	-	
Waits until all running operations are complete	*WAI	-	-	

*1: If the *DDT? command is executed when the macro is undefined, a zero-length block data (#10) is returned.

*2: <str> is output in the following format: maker name, model name, serial number and version number.

*3: POFF indicates the parameter settings when the power was last switched off.

6.3 List of Commands

6.3 List of Commands

6.3.1 Subsystem-SYSTEM

Function description	SCPI command	Parameter	Query reply	Remarks
Config				
Measurement system selection	:SYSTEM:SElect	SANalyzer MANalyzer	SAN MAN	
Modulation				
Modulation analysis system selection	:SYSTEM:SElect:MODulation	VMANalysis	VMAN	
Preset				
Each measurement system parameter initialization	:SYSTEM:PRESet	-	-	
All measurement systems initialization	:SYSTEM:PRESet:ALL	-	-	
Log				
Inquiry about the error that occurred last	:SYSTEM:ERRor	-	<int>,<str>	
Inquiry about the details of the error log	:SYSTEM:ERRor:ALL	-	<int>,<str>	

6.3.2 Subsystem-INPut

Function description	SCPI command	Parameter	Query reply	Remarks
ATT/Preamp				
ATT setting (Manual)	:INPut:ATTenuation	<real>	<real>	
ATT(Auto/Manual)	:INPut:ATTenuation:AUTO	OFF ON	OFF ON	
Min ATT setting	:INPut:ATTenuation:MINimum	<real>	<real>	
Min ATT ON/OFF	:INPut:ATTenuation:MINimum:STATe	OFF ON	OFF ON	
Preamp ON/OFF	:INPut:GAIN:STATe	OFF ON	OFF ON	
Input Setup				
Input Signal RF/Baseband	:INPut:SIGNal	RF BASEband	RF BAS	
Baseband Input AC/DC	:INPut:BASEband	AC DC	AC DC	
IQ Inverse ON/OFF	:INPut:IQ:INVerse	OFF ON	OFF ON	

6.3.3 Subsystem-SENSE

Function description	SCPI command	Parameter	Query reply	Remarks
Frequency				
Center Freq setting	[[:SENSE]:FREQUENCY:CENTER	<real>	<real>	
Freq Offset setting	[[:SENSE]:FREQUENCY:OFFSet	<real>	<real>	
Freq Offset ON/OFF	[[:SENSE]:FREQUENCY:OFFSet:STATe	OFF ON	OFF ON	
Channel Number setting	[[:SENSE]:FREQUENCY:CHANnel:NUMBer	<int>	<int>	
Auto Level Set				
Auto Level Set execution	[[:SENSE]:POWER:LEVel:AUTO	-	-	
Measurement Parameters				
Symbol Rate setting	[[:SENSE]:CONDition:SRATe	<real>	<real>	
Modulation Format selection	[[:SENSE]:CONDition:MFORMAT	BPSK QPSK P4DQPSK PSK8 QAM16 QAM32 QAM64 QAM128 QAM256 FSK MSK	BPSK QPSK P4DQPSK PSK8 QAM16 QAM32 QAM64 QAM128 QAM256 FSK MSK	
Differential Code ON/OFF	[[:SENSE]:CONDition:DCODE	OFF ON	OFF ON	
A/D Capture Length setting	[[:SENSE]:CONDition:CAPTure:LENGTh	<int>	<int>	
Analysis Length setting	[[:SENSE]:CONDition:ANALYsis:LENGTh	<int>	<int>	
Burst Search ON/OFF	[[:SENSE]:CONDition:BSFarch	OFF ON	OFF ON	
Search Threshold setting	[[:SENSE]:CONDition:STHReshold	<real>	<real>	
Amplitude Synchronization ON/OFF	[[:SENSE]:CONDition:ASYNchronization	OFF ON	OFF ON	
Analysis Start Offset setting	[[:SENSE]:CONDition:ASOFFset	<int>	<int>	
Compensate Origin Offset setting	[[:SENSE]:CONDition:COOFset	OFF ON	OFF ON	
EVM Calculation Method RMS/Max	[[:SENSE]:CONDition:ECMethod	RMS MAXimum	RMS MAX	
Synchronous Parameters				
Synchronization ON/OFF	[[:SENSE]:CONDition:SYNChronization	OFF ON	OFF ON	
Synchronous Word setting	[[:SENSE]:CONDition:SYNChronous:WORD	<str>	<str>	Hexadecimal character string
Synchronous Length setting	[[:SENSE]:CONDition:SYNChronous:LENGTh	<int>	<int>	
Synchronous Offset setting	[[:SENSE]:CONDition:SYNChronous:OFFSet	<int>	<int>	

6.3.3 Subsystem-SENSe

Function description	SCPI command	Parameter	Query reply	Remarks
Filter Parameters				
Meas Filter Type Nyquist/ Root Nyquist/Gauss/Sinc/ User	[[:SENSe]:CONDition:MFILter:TYPE	NYQuist RNYQuist GAUSS SINC USER	NYQ RNYQ GAUS SINC USER	
Load Meas Filter execution	[[:SENSe]:CONDition:MFILter:LOAD	<str>	-	Absolute path to the file
Meas Filter Parameter setting	[[:SENSe]:CONDition:MFILter:PARAMeter	<real>	<real>	
Meas Filter Tap setting	[[:SENSe]:CONDition:MFILter:TAP	<int>	<int>	
Ref Filter Type Nyquist/Root Nyquist/Gauss/Rect/User	[[:SENSe]:CONDition:RFILter:TYPE	NYQuist RNYQuist GAUSS RECT USER	NYQ RNYQ GAUS RECT USER	
Load Ref Filter execution	[[:SENSe]:CONDition:RFILter:LOAD	<str>	-	Absolute path to the file
Ref Filter Parameter setting	[[:SENSe]:CONDition:RFILter:PARAMeter	<real>	<real>	
Ref Filter Tap setting	[[:SENSe]:CONDition:RFILter:TAP	<int>	<int>	
Standard				
Standard setting (PDC)	[[:SENSe]:CONDition:STANdard:PDC	-	-	
Standard setting (GSM)	[[:SENSe]:CONDition:STANdard:GSM	-	-	
Standard setting (PHS)	[[:SENSe]:CONDition:STANdard:PHS	-	-	
Standard setting (DECT)	[[:SENSe]:CONDition:STANdard:DECT	-	-	
Standard setting (CDPD)	[[:SENSe]:CONDition:STANdard:CDPD	-	-	
Standard setting (TETRA)	[[:SENSe]:CONDition:STANdard:TETRA	-	-	
Standard setting (DVB-C)	[[:SENSe]:CONDition:STANdard:DVBC	-	-	
Standard setting (Bluetooth)	[[:SENSe]:CONDition:STANdard:BLUETOOTH	-	-	
Average				
Average ON/OFF	[[:SENSe]:CONDition:AVERAge[:STATe]	OFF ON	OFF ON	
Average setting	[[:SENSe]:CONDition:AVERAge:COUNt	<int>	<int>	
Average Peak Type Hold/ Average	[[:SENSe]:CONDition:AVERAge:PTYPe	HOLD AVERAge	HOLD AVER	
Average Refresh Cycle set- ting	[[:SENSe]:CONDition:AVERAge:RCYCLE	<int>	<int>	
Equalizing Filter				
Equalizing Filter creation	[[:SENSe]:CONDition:EQUAlizer:MAKE	-	-	
Equalizing Filter ON/OFF	[[:SENSe]:CONDition:EQUAlizer	OFF ON	OFF ON	

6.3.4 Subsystem-TRIGger

Function description	SCPI command	Parameter	Query reply	Remarks
Sequence				
Trigger Source	:TRIGger[:SEquence]:SOURce	IMMediate IF EXternal1 EXternal2 LINK	IMM IF EXT1 EXT2 LINK	
Trigger Slope	:TRIGger[:SEquence]:SLOPe	POSitive NEGative	POS NEG	
IF Power setting	:TRIGger[:SEquence]:LEVel:IF	<real>	<real>	
Ext2 Trigger Level setting	:TRIGger[:SEquence]:LEVel:EXternal	<real>	<real>	
Trigger Delay setting	:TRIGger[:SEquence]:DELay	<real>	<real>	

6.3.5 Subsystem-INITiate

Function description	SCPI command	Parameter	Query reply	Remarks
Initiate				
Single measurement execution	:INITiate:MEASure:SINGle	-	-	
Repeat measurement execution	:INITiate:MEASure:REPeat	-	-	
Analysis execution	:INITiate:REStart	-	-	
Stop execution	:INITiate:ABORt	-	-	

6.3.6 Subsystem-CALCulate

Function description	SCPI command	Parameter	Query reply	Remarks
Marker				
Marker ON/OFF	:CALCulate:MARKer<scrn=1 2 3 4>[:STATe]	OFF ON	OFF ON	
Marker X setting	:CALCulate:MARKer<scrn=1 2 3 4>:X	<real>	<real>	
Marker Y reading	:CALCulate:MARKer<scrn=1 2 3 4>:Y	-	<real>	
Marker setting on the Constellation and Eye displays	:CALCulate:MARKer<scrn=1 2 3 4>:SYMBOL	<real>	<real>	
I reading on the Constellation and Eye displays	:CALCulate:MARKer<scrn=1 2 3 4>:I	-	<real>	<I>
Q reading on the Constellation and Eye displays	:CALCulate:MARKer<scrn=1 2 3 4>:Q	-	<real>	<Q>
Marker Interlock ON/OFF	:CALCulate:MARKer:ILOCK	OFF ON	OFF ON	
Δ Marker ON/OFF	:CALCulate:DELTAmarker<scrn=1 2 3 4>[:STATe]	OFF ON	OFF ON	
Peak Search execution	:CALCulate:MARKer<scrn=1 2 3 4>:MAXimum	-	-	

6.3.7 Subsystem-DISPLAY

6.3.7 Subsystem-DISPLAY

Function description	SCPI command	Parameter	Query reply	Remarks
Level				
Ref Level setting	:DISPlay:TRACe:Y[:SCALe]:RLEVel	<real>	<real>	
Level Offset setting	:DISPlay:TRACe:Y[:SCALe]:RLEVel:OFFSet	<real>	<real>	
Level Offset ON/OFF	:DISPlay:TRACe:Y[:SCALe]:RLEVel:OFFSet:STATe	OFF ON	OFF ON	
Display				
Multi Screen setting	:DISPlay	SINGLe DUAL QUAD	SING DUAL QUAD	
Window Format selection	:DISPlay[:WINDow<scrm=1 2 3 4>]:FOrMat	PSYMBOL PSPeSpectrum ESYMBOL ESPeSpectrum MESYMBOL MESPeSpectrum PESYMBOL PESPeSpectrum PHSYMBOL PHSPeSpectrum FSYMBOL FSPeSpectrum CONStellation IEYE QEYE TMCHAracteristics TPCHAracteristics DDATa TRESult	PSYM PSP FSYM FSP MESY MESP PESY PESP PHSY FSYM FHYE CONS IEYE QEYE TMCH TPCH DDAT TRES	
Display Type vs Symbol setting	:DISPlay[:WINDow<scrm=1 2 3 4>]:SYMBOL:TRACe:TYPE	TSYMBOL SYMBOL TRACe	TSYM SYMB TRAC	
Display Type Constellation setting	:DISPlay[:WINDow<scrm=1 2 3 4>]:CONStellation:TRACe:TYPE	TSYMBOL SYMBOL LINE	TSYM SYMB LINE	
Scale				
Scale Interlock ON/OFF	:DISPlay:SCALe:ILOck	OFF ON	OFF ON	
Auto Scale execution	:DISPlay[:WINDow<scrm=1 2 3 4>]:SCALe:AUTO	-	-	
Symbol Start setting	:DISPlay[:WINDow<scrm=1 2 3 4>]:TRACe:SYMBOL:STARt	<int>	<int>	
Symbol Stop setting	:DISPlay[:WINDow<scrm=1 2 3 4>]:TRACe:SYMBOL:STOP	<int>	<int>	
X Scale Left setting	:DISPlay[:WINDow<scrm=1 2 3 4>]:TRACe:X[:SCALe]:LEFt	<real>	<real>	
X Scale Right setting	:DISPlay[:WINDow<scrm=1 2 3 4>]:TRACe:X[:SCALe]:RIGHt	<real>	<real>	
Y Scale Upper setting	:DISPlay[:WINDow<scrm=1 2 3 4>]:TRACe:Y[:SCALe]:UPPER	<real>	<real>	
Y Scale Lower setting	:DISPlay[:WINDow<scrm=1 2 3 4>]:TRACe:Y[:SCALe]:LOWER	<real>	<real>	

6.3.8 Subsystem-MMEMory

Function description	SCPI command	Parameter	Query reply	Remarks
Save/Recall				
Saving the settings of this instrument	:MMEMory:STORe:STATe	<int>	-	*1
Loading the settings of this instrument	:MMEMory:LOAD:STATe	<int>	-	*1
Measurement condition Save selection	:MMEMory:SELect:ITEM:VMANalysis:SETup	OFF ON	OFF ON	
Save Demod Data execution	:MMEMory:STORe:DDATa:STATe	<int>	-	*1

*1: A number, which is a maximum of 4-digit and is added to the file name of the data to be saved or loaded, must be specified in <int>.

6.3.9 Subsystem-MEASure

Function description	SCPI command	Parameter	Query reply	Remarks
Total Result(Common)				
Frequency Error reading	:MEASure:TRESult:FERRor	-	<real>,<real>	<Hz>, <ppm>
Frequency reading	:MEASure:TRESult:FREQuency	-	<real>	
Tx Power reading	:MEASure:TRESult:POWER	-	<real>,<real>	<dBm>, <W>
Peak Power reading	:MEASure:TRESult:PEAK:POWER	-	<real>,<real>	<dBm>, <W>
Peak Factor reading	:MEASure:TRESult:PEAK:FACTOR	-	<real>	
IQ Origin Offset reading	:MEASure:TRESult:IQOffset	-	<real>	
Amp Droop reading	:MEASure:TRESult:ADRoop	-	<real>	
Total Result(Not FSK)				
EVM reading	:MEASure:TRESult:EVM	-	<real>,<real>,<int>	<RMS>,<Peak>,<Peak Symbol>
Mag Error reading	:MEASure:TRESult:MERRor	-	<real>,<real>,<int>	<RMS>,<Peak>,<Peak Symbol>
Phase Error reading	:MEASure:TRESult:PERRor	-	<real>,<real>,<int>	<RMS>,<Peak>,<Peak Symbol>
IQ Imbalance reading	:MEASure:TRESult:IQImbalance	-	<real>	
Orthogonal Error reading	:MEASure:TRESult:OERRor	-	<real>	
IQ Skew reading	:MEASure:TRESult:IQSkew	-	<real>,<real>	<sec>,<UI>
Symbol Rate Error reading	:MEASure:TRESult:SRERror	-	<real>,<real>	<Hz>,<ppm>
Total Result(FSK)				
Max Deviation reading	:MEASure:TRESult:DEVIation:MAXimum	-	<real>,<int>	<Hz>,<Symbol>
Min Deviation reading	:MEASure:TRESult:DEVIation:MINimum	-	<real>,<int>	<Hz>,<Symbol>
Min/Max Deviation reading	:MEASure:TRESult:DEVIation:RATE	-	<real>	

6.3.9 Subsystem-MEASure

Function description	SCPI command	Parameter	Query reply	Remarks
Trace Data				
Power vs Symbol X data reading	:MEASure:PSYMBOL:X	-	<block> or <ASCII>	*2
Power vs Symbol Y data reading	:MEASure:PSYMBOL:Y	-	<block> or <ASCII>	*2
Power Spectrum X data reading	:MEASure:PSpectrum:X	-	<block> or <ASCII>	*2
Power Spectrum Y data reading	:MEASure:PSpectrum:Y	-	<block> or <ASCII>	*2
EVM vs Symbol X data reading	:MEASure:ESYMBOL:X	-	<block> or <ASCII>	*2
EVM vs Symbol Y data reading	:MEASure:ESYMBOL:Y	-	<block> or <ASCII>	*2
EVM Spectrum X data reading	:MEASure:ESpectrum:X	-	<block> or <ASCII>	*2
EVM Spectrum Y data reading	:MEASure:ESpectrum:Y	-	<block> or <ASCII>	*2
Mag Error vs Symbol X data reading	:MEASure:MESYMBOL:X	-	<block> or <ASCII>	*2
Mag Error vs Symbol Y data reading	:MEASure:MESYMBOL:Y	-	<block> or <ASCII>	*2
Mag Error Spectrum X data reading	:MEASure:MESpectrum:X	-	<block> or <ASCII>	*2
Mag Error Spectrum Y data reading	:MEASure:MESpectrum:Y	-	<block> or <ASCII>	*2
Phase Error vs Symbol X data reading	:MEASure:PESYMBOL:X	-	<block> or <ASCII>	*2
Phase Error vs Symbol Y data reading	:MEASure:PESYMBOL:Y	-	<block> or <ASCII>	*2
Phase Error Spectrum X data reading	:MEASure:PESpectrum:X	-	<block> or <ASCII>	*2
Phase Error Spectrum Y data reading	:MEASure:PESpectrum:Y	-	<block> or <ASCII>	*2
Phase vs Symbol X data reading	:MEASure:PHSYMBOL:X	-	<block> or <ASCII>	*2
Phase vs Symbol Y data reading	:MEASure:PHSYMBOL:Y	-	<block> or <ASCII>	*2
Frequency vs Symbol X data reading	:MEASure:FSYMBOL:X	-	<block> or <ASCII>	*2
Frequency vs Symbol Y data reading	:MEASure:FSYMBOL:Y	-	<block> or <ASCII>	*2
Frequency Eye Diagram data reading	:MEASure:FYE	-	<block> or <ASCII>	*2
Constellation I data reading	:MEASure:CONStellation:I	-	<block> or <ASCII>	*2
Constellation Q data reading	:MEASure:CONStellation:Q	-	<block> or <ASCII>	*2

Function description	SCPI command	Parameter	Query reply	Remarks
Transmission Mag Characteristics X data reading	:MEASure:TMCHaracteristics:X	-	<block> or <ASCII>	*2
Transmission Mag Characteristics Y data reading	:MEASure:TMCHaracteristics:Y	-	<block> or <ASCII>	*2
Transmission Phase Characteristics X data reading	:MEASure:TPCHaracteristics:X	-	<block> or <ASCII>	*2
Transmission Phase Characteristics Y data reading	:MEASure:TPCHaracteristics:Y	-	<block> or <ASCII>	*2
Demodulated Data				
Synchronous Judgment reading	:MEASure:DDATa:SYNChronous:JUDGment	-	NSYN SYNC	
Demodulated Data reading	:MEASure:DDATa	-	<ASCII>	*2

*2: Data of the measurement length is output.

6.3.10 Subsystem-READ

6.3.10 Subsystem-READ

Function description	SCPI command	Parameter	Query reply	Remarks
Total Result(Common)				
Frequency Error reading	:READ:TRESult:FERRor	-	<real>,<real>	<Hz>,<ppm>
Frequency reading	:READ:TRESult:FREQuency	-	<real>	
Tx Power reading	:READ:TRESult:POWEr	-	<real>,<real>	<dBm>,<W>
Peak Power reading	:READ:TRESult:PEAK:POWEr	-	<real>,<real>	<dBm>,<W>
Peak Factor reading	:READ:TRESult:PEAK:FACTor	-	<real>	
IQ Origin Offset reading	:READ:TRESult:IQOFFset	-	<real>	
Amp Droop reading	:READ:TRESult:ADRoop	-	<real>	
Total Result(Not FSK)				
EVM reading	:READ:TRESult:EVM	-	<real>,<real>,<int>	<RMS>,<Peak>,<Peak Symbol>
Mag Error reading	:READ:TRESult:MERRor	-	<real>,<real>,<int>	<RMS>,<Peak>,<Peak Symbol>
Phase Error reading	:READ:TRESult:PERRor	-	<real>,<real>,<int>	<RMS>,<Peak>,<Peak Symbol>
IQ Imbalance reading	:READ:TRESult:IQIMbalance	-	<real>	
Orthogonal Error reading	:READ:TRESult:OERRor	-	<real>	
IQ Skew reading	:READ:TRESult:IQSKew	-	<real>,<real>	<sec>,<UI>
Symbol Rate Error reading	:READ:TRESult:SRERRor	-	<real>,<real>	<Hz>,<ppm>
Total Result(FSK)				
Max Deviation reading	:READ:TRESult:DEVIation:MAXimum	-	<real>,<int>	<Hz>,<Symbol>
Min Deviation reading	:READ:TRESult:DEVIation:MINimum	-	<real>,<int>	<Hz>,<Symbol>
Min/Max Deviation reading	:READ:TRESult:DEVIation:RATE	-	<real>	
Trace Data				
Power vs Symbol X data reading	:READ:PSYMBOL:X	-	<block> or <ASCII>	*2
Power vs Symbol Y data reading	:READ:PSYMBOL:Y	-	<block> or <ASCII>	*2
Power Spectrum X data reading	:READ:PSPepectrum:X	-	<block> or <ASCII>	*2
Power Spectrum Y data reading	:READ:PSPepectrum:Y	-	<block> or <ASCII>	*2
EVM vs Symbol X data reading	:READ:ESYMBOL:X	-	<block> or <ASCII>	*2
EVM vs Symbol Y data reading	:READ:ESYMBOL:Y	-	<block> or <ASCII>	*2
EVM Spectrum X data reading	:READ:ESPepectrum:X	-	<block> or <ASCII>	*2
EVM Spectrum Y data reading	:READ:ESPepectrum:Y	-	<block> or <ASCII>	*2

Function description	SCPI command	Parameter	Query reply	Remarks
Mag Error vs Symbol X data reading	:READ:MESYmbol:X	-	<block> or <ASCII>	*2
Mag Error vs Symbol Y data reading	:READ:MESYmbol:Y	-	<block> or <ASCII>	*2
Mag Error Spectrum X data reading	:READ:MESpectrum:X	-	<block> or <ASCII>	*2
Mag Error Spectrum Y data reading	:READ:MESpectrum:Y	-	<block> or <ASCII>	*2
Phase Error vs Symbol X data reading	:READ:PESYmbol:X	-	<block> or <ASCII>	*2
Phase Error vs Symbol Y data reading	:READ:PESYmbol:Y	-	<block> or <ASCII>	*2
Phase Error Spectrum X data reading	:READ:PESpectrum:X	-	<block> or <ASCII>	*2
Phase Error Spectrum Y data reading	:READ:PESpectrum:Y	-	<block> or <ASCII>	*2
Phase vs Symbol X data reading	:READ:PHSYmbol:X	-	<block> or <ASCII>	*2
Phase vs Symbol Y data reading	:READ:PHSYmbol:Y	-	<block> or <ASCII>	*2
Frequency vs Symbol X data reading	:READ:FSYmbol:X	-	<block> or <ASCII>	*2
Frequency vs Symbol Y data reading	:READ:FSYmbol:Y	-	<block> or <ASCII>	*2
Frequency Eye Diagram data reading	:READ:FEYE	-	<block> or <ASCII>	*2
Constellation I data reading	:READ:CONStellation:I	-	<block> or <ASCII>	*2
Constellation Q data reading	:READ:CONStellation:Q	-	<block> or <ASCII>	*2
Transmission Mag Characteristics X data reading	:READ:TMCHaracteristics:X	-	<block> or <ASCII>	*2
Transmission Mag Characteristics Y data reading	:READ:TMCHaracteristics:Y	-	<block> or <ASCII>	*2
Transmission Phase Characteristics X data reading	:READ:TPCHaracteristics:X	-	<block> or <ASCII>	*2
Transmission Phase Characteristics Y data reading	:READ:TPCHaracteristics:Y	-	<block> or <ASCII>	*2
Demodulated Data				
Synchronous Judgment reading	:READ:DDATa:SYNChronous:JUDGment	-	NSYN SYNC	
Demodulated Data reading	:READ:DDATa	-	<ASCII>	*2

*2: Data of the measurement length is output.

6.3.11 Subsystem-FETCH

6.3.11 Subsystem-FETCH

Function description	SCPI command	Parameter	Query reply	Remarks
Total Result(Common)				
Frequency Error reading	:FETCH:TRESult:FERRor	-	<real>,<real>	<Hz>,<ppm>
Frequency reading	:FETCH:TRESult:FRFQuency	-	<real>	
Tx Power reading	:FETCH:TRESult:POWEr	-	<real>,<real>	<dBm>,<W>
Peak Power reading	:FETCH:TRESult:PEAK:POWEr	-	<real>,<real>	<dBm>,<W>
Peak Factor reading	:FETCH:TRESult:PEAK:FACTor	-	<real>	
IQ Origin Offset reading	:FETCH:TRESult:IQOFset	-	<real>	
Amp Droop reading	:FETCH:TRESult:ADRoop	-	<real>	
Total Result(Not FSK)				
EVM reading	:FETCH:TRESult:EVM	-	<real>,<real>,<int>	<RMS>,<Peak>,<Peak Symbol>
Mag Error reading	:FETCH:TRESult:MERRor	-	<real>,<real>,<int>	<RMS>,<Peak>,<Peak Symbol>
Phase Error reading	:FETCH:TRESult:PERRor	-	<real>,<real>,<int>	<RMS>,<Peak>,<Peak Symbol>
IQ Imbalance reading	:FETCH:TRESult:IQIMbalance	-	<real>	
Orthogonal Error reading	:FETCH:TRESult:OERRor	-	<real>	
IQ Skew reading	:FETCH:TRESult:IQSkew	-	<real>,<real>	<sec>,<UI>
Symbol Rate Error reading	:FETCH:TRESult:SRERRor	-	<real>,<real>	<Hz>,<ppm>
Total Result(FSK)				
Max Deviation reading	:FETCH:TRESult:DEViation:MAXimum	-	<real>,<int>	<Hz>,<Symbol>
Min Deviation reading	:FETCH:TRESult:DEViation:MINimum	-	<real>,<int>	<Hz>,<Symbol>
Min/Max Deviation reading	:FETCH:TRESult:DEViation:RATE	-	<real>	
Trace Data				
Power vs Symbol X data reading	:FETCH:PSYMBOL:X	-	<block> or <ASCII>	*2
Power vs Symbol Y data reading	:FETCH:PSYMBOL:Y	-	<block> or <ASCII>	*2
Power Spectrum X data reading	:FETCH:PSPECTrum:X	-	<block> or <ASCII>	*2
Power Spectrum Y data reading	:FETCH:PSPECTrum:Y	-	<block> or <ASCII>	*2
EVM vs Symbol X data reading	:FETCH:ESYMBOL:X	-	<block> or <ASCII>	*2
EVM vs Symbol Y data reading	:FETCH:ESYMBOL:Y	-	<block> or <ASCII>	*2
EVM Spectrum X data reading	:FETCH:ESPECTrum:X	-	<block> or <ASCII>	*2
EVM Spectrum Y data reading	:FETCH:ESPECTrum:Y	-	<block> or <ASCII>	*2

Function description	SCPI command	Parameter	Query reply	Remarks
Mag Error vs Symbol X data reading	:FETCh:MESSymbol:X	-	<block> or <ASCII>	*2
Mag Error vs Symbol Y data reading	:FETCh:MESSymbol:Y	-	<block> or <ASCII>	*2
Mag Error Spectrum X data reading	:FETCh:MESpectrum:X	-	<block> or <ASCII>	*2
Mag Error Spectrum Y data reading	:FETCh:MESpectrum:Y	-	<block> or <ASCII>	*2
Phase Error vs Symbol X data reading	:FETCh:PESymbol:X	-	<block> or <ASCII>	*2
Phase Error vs Symbol Y data reading	:FETCh:PESymbol:Y	-	<block> or <ASCII>	*2
Phase Error Spectrum X data reading	:FETCh:PESpectrum:X	-	<block> or <ASCII>	*2
Phase Error Spectrum Y data reading	:FETCh:PESpectrum:Y	-	<block> or <ASCII>	*2
Phase vs Symbol X data reading	:FETCh:PHSymbol:X	-	<block> or <ASCII>	*2
Phase vs Symbol Y data reading	:FETCh:PHSymbol:Y	-	<block> or <ASCII>	*2
Frequency vs Symbol X data reading	:FETCh:FSymbol:X	-	<block> or <ASCII>	*2
Frequency vs Symbol Y data reading	:FETCh:FSymbol:Y	-	<block> or <ASCII>	*2
Frequency Eye Diagram data reading	:FETCh:FEYE	-	<block> or <ASCII>	*2
Constellation I data reading	:FETCh:CONStellation:I	-	<block> or <ASCII>	*2
Constellation Q data reading	:FETCh:CONStellation:Q	-	<block> or <ASCII>	*2
Transmission Mag Characteristics X data reading	:FETCh:TMCharacteristics:X	-	<block> or <ASCII>	*2
Transmission Mag Characteristics Y data reading	:FETCh:TMCharacteristics:Y	-	<block> or <ASCII>	*2
Transmission Phase Characteristics X data reading	:FETCh:TPCharacteristics:X	-	<block> or <ASCII>	*2
Transmission Phase Characteristics Y data reading	:FETCh:TPCharacteristics:Y	-	<block> or <ASCII>	*2
Demodulated Data				
Synchronous Judgment reading	:FETCh:DDATa:SYNChronous:JUDGment	-	NSYN SYNC	
Demodulated Data reading	:FETCh:DDATa	-	<ASCII>	*2

*2: Data of the measurement length is output.

6.3.12 Subsystem-FORMat

6.3.12 Subsystem-FORMat

Function description	SCPI command	Parameter	Query reply	Remarks
FORMat				
Trace data output byte order setting	:FORMat:BOReD[:DATA]	NORMal SWAPped	NORM SWAP	
Trace data output format setting	:FORMat:TRACe[:DATA]	REAL ASCIi,<int>	REAL ASC,<int>	*3

*3: <int> is selected from {32|64} for REAL and {8|9|10|...|21|22} for ASCII.

6.3.13 Subsystem-STATus

Function description	SCPI command	Parameter	Query reply	Remarks
Status				
Standard Operation Enable Register setting	:STATus:OPERation:ENABle	<int>	<int>	
Standard Operation Event Register setting	:STATus:OPERation:EVENT	-	<int>	
Questionable Enable Register setting	:STATus:QUEStionable:ENABle	<int>	<int>	
Questionable Event Register setting	:STATus:QUEStionable:EVENT	-	<int>	
Measuring Enable Register setting	:STATus:OPERation:MEASure:ENABle	<int>	<int>	
Measuring Operation Event Register setting	:STATus:OPERation:MEASure:EVENT	-	<int>	

6.3.14 Subsystem-HCOPy

Function description	SCPI command	Parameter	Query reply	Remarks
Hcopy				
Copy output to the file or printer	:HCOPy[:IMMediate]	-	-	
Specification of the output destination (file or printer)	:HCOPy:DEStination	MMEMOry PRINt	MMEM PRIN	
Specification of the output file number	:HCOPy:MMEMOry:FILE:NUMBer	<int>	<int>	
Specification of the output file type	:HCOPy:MMEMOry:FILE:TYPE	BITMap PNGraphic	BITM PNG	

6.4 Status Register




Figure 6-1 Status Registers

7. PERFORMANCE VERIFICATION

This chapter describes how to verify whether this instrument meets the specified performance.

It is recommended that you copy the test data record sheet included in the last of this chapter and save it as a record of the performance test.

IMPORTANT: Before executing the performance verification, execute warm-up and all calibrations.

7.1 Test Signal Specifications

The test signals used for performance verification are shown below:

Table 7-1 Test Signal Specifications (1 of 2)

No.	Test signal name	Signal specifications	Test item
1	8PSK Signal	Carrier frequency : 2 GHz (only RF input) Power : -10 dBm (only RF input) Input voltage : 1 Vpp (only IQ input) Symbol rate : 1 MHz Modulation format : 8PSK Transmission filter : Nyquist, $\alpha=0.5$	Power measurement (only RF input) Carrier frequency error measurement EVM measurement
2	256QAM Signal	Carrier frequency : 2 GHz (only RF input) Power : -10 dBm (only RF input) Input voltage : 1 Vpp (only IQ input) Symbol rate : 1 MHz Modulation format : 256QAM Transmission filter : Nyquist, $\alpha=0.5$ EVM Calculation Method : RMS	Power measurement (only RF input) Carrier frequency error measurement EVM measurement
3	MSK Signal	Carrier frequency : 2 GHz (only RF input) Power : -10 dBm (only RF input) Input voltage : 1 Vpp (only IQ input) Symbol rate : 1 MHz Modulation format : MSK Transmission filter : Gauss, BT=0.3	Power measurement (only RF input) Carrier frequency error measurement EVM measurement

7.1 Test Signal Specifications

Table 7-1 Test Signal Specifications (2 of 2)

No.	Test signal name	Signal specifications	Test item
4	FSK Signal	Carrier frequency : 2 GHz (only RF input) Power : -10 dBm (only RF input) Input voltage : 1 Vpp (only IQ input) Symbol rate : 1 MHz Modulation format : FSK Modulation index : 0.32 Transmission filter : Gauss, BT=0.5	Power measurement (only RF input) Carrier frequency error measurement Max Deviation measurement

7.2 Test Procedures

This section describes the procedures of each test item.

7.2.1 RF Input Test Signal Measurement

Connect the signal source as shown below.




Figure 7-1 Connection Diagram of Signal Source (RF Input)

7.2.1.1 8PSK Measurement

1. Output the 8PSK signal, which has a carrier frequency of 2 GHz and a level of -10 dBm, from the signal source.
2. Set this instrument as follows:

{MEAS SETUP}:

Meas Parameters

[Symbol Rate]	1000000
[Modulation Format]	8PSK
[Differential Code]	OFF
[A/D Capture Length]	1500
[Analysis Length]	1500
[Burst Search]	OFF
[Compensate Origin Offset]	ON
[EVM Calculation Method]	RMS

Synchronous Parameters

[Synchronization]	OFF
-------------------	-----

Filter Parameters

[Meas Filter]	
[Filter Type]	Sinc

7.2.1 RF Input Test Signal Measurement

	[Filter Parameter]	0.5
	[Filter Tap]	20
	[Ref Filter]	
	[Filter Type]	Nyquist
	[Filter Parameter]	0.5
	[Filter Tap]	20
	Average	
	[Average times]	OFF
	Equalizing Filter	OFF
{INPUT}:	Input	RF
	IQ Inverse	OFF
{TRIGGER}:	Trigger Source	Free Run
{FREQ}:	Center	2 GHz
{LEVEL}:	Execute Auto Level Set	

3. Press the **SINGLE** button on this unit to perform measurements.
4. Write the measurement results in the test data record sheet.

7.2.1.2 256QAM Measurement

1. Output the 256QAM signal, which has a carrier frequency of 2 GHz and a level of -10 dBm, from the signal source.
2. Set this instrument as follows:

{MEAS SETUP}:	Meas Parameters	
	[Symbol Rate]	1000000
	[Modulation Format]	256QAM
	[Differential Code]	OFF
	[A/D Capture Length]	1500
	[Analysis Length]	1500
	[Burst Search]	OFF
	[Compensate Origin Offset]	ON
	[EVM Calculation Method]	RMS
	Synchronous Parameters	
	[Synchronization]	OFF
	Filter Parameters	
	[Meas Filter]	
	[Filter Type]	Sinc
	[Filter Parameter]	0.5
	[Filter Tap]	20

	[Ref Filter]	
	[Filter Type]	Nyquist
	[Filter Parameter]	0.5
	[Filter Tap]	20
	Average	
	[Average times]	OFF
	Equalizing Filter	OFF
{INPUT}:	Input	RF
	IQ Inverse	OFF
{TRIGGER}:	Trigger Source	Free Run
{FREQ}:	Center	2 GHz
{LEVEL}:	Execute Auto Level Set	

3. Press the **SINGLE** button on this unit to perform measurements.
4. Write the measurement results in the test data record sheet.

7.2.1.3 MSK Measurement

1. Output the MSK signal, which has a carrier frequency of 2 GHz and a level of -10 dBm, from the signal source.
2. Set this instrument as follows:

{MEAS SETUP}:	Meas Parameters	
	[Symbol Rate]	1000000
	[Modulation Format]	MSK
	[Differential Code]	OFF
	[A/D Capture Length]	1500
	[Analysis Length]	1500
	[Burst Search]	OFF
	[Compensate Origin Offset]	ON
	[EVM Calculation Method]	RMS
	Synchronous Parameters	
	[Synchronization]	OFF
	Filter Parameters	
	[Meas Filter]	
	[Filter Type]	Sinc
	[Filter Parameter]	0.5
	[Filter Tap]	20
	[Ref Filter]	
	[Filter Type]	Gauss

7.2.1 RF Input Test Signal Measurement

	[Filter Parameter]	0.3
	[Filter Tap]	20
	Average	
	[Average times]	OFF
	Equalizing Filter	OFF
{INPUT}:	Input	RF
	IQ Inverse	OFF
{TRIGGER}:	Trigger Source	Free Run
{FREQ}:	Center	2 GHz
{LEVEL}:	Execute Auto Level Set	

3. Press the **SINGLE** button on this unit to perform measurements.
4. Write the measurement results in the test data record sheet.

7.2.1.4 FSK Measurement

1. Output the FSK signal, which has a carrier frequency of 2 GHz and a level of -10 dBm, from the signal source.
2. Set this instrument as follows:

{MEAS SETUP}:	Meas Parameters	
	[Symbol Rate]	1000000
	[Modulation Format]	FSK
	[Differential Code]	OFF
	[A/D Capture Length]	1500
	[Analysis Length]	1500
	[Burst Search]	OFF
	[Compensate Origin Offset]	ON
	Synchronous Parameters	
	[Synchronization]	OFF
	Filter Parameters	
	[Meas Filter]	
	[Filter Type]	Sinc
	[Filter Parameter]	0.5
	[Filter Tap]	20
	[Ref Filter]	
	[Filter Type]	Gauss
	[Filter Parameter]	0.5
	[Filter Tap]	20

	Average	
	[Average times]	OFF
{INPUT}:	Input	RF
	IQ Inverse	OFF
{TRIGGER}:	Trigger Source	Free Run
{FREQ}:	Center	2 GHz
{LEVEL}:	Execute Auto Level Set	

3. Press the **SINGLE** button on this unit to perform measurements.
4. Write the measurement results in the test data record sheet.

7.2.2 IQ Input Test Signal Measurement

7.2.2 IQ Input Test Signal Measurement

Connect the signal source as shown below.




Figure 7-2 Connection Diagram of Signal Source (IQ Input)

7.2.2.1 8PSK Measurement

1. Output the 8PSK signal that has a voltage of 1 Vpp from the signal source.
2. Set this instrument as follows:

{MEAS SETUP}:

Meas Parameters	
[Symbol Rate]	1000000
[Modulation Format]	8PSK
[Differential Code]	OFF
[A/D Capture Length]	1500
[Analysis Length]	1500
[Burst Search]	OFF
[Compensate Origin Offset]	ON
[EVM Calculation Method]	RMS
Synchronous Parameters	
[Synchronization]	OFF
Filter Parameters	
[Meas Filter]	
[Filter Type]	Sinc
[Filter Parameter]	0.5
[Filter Tap]	20
[Ref Filter]	
[Filter Type]	Nyquist
[Filter Parameter]	0.5

	[Filter Tap]	20
	Average	
	[Average times]	OFF
	Equalizing Filter	OFF
{INPUT}:	Input	Baseband(I&Q)
	Baseband Input	DC
	IQ Inverse	OFF
{TRIGGER}:	Trigger Source	Free Run

3. Press the **SINGLE** button on this unit to perform measurements.
4. Write the measurement results in the test data record sheet.

7.2.2.2 256QAM Measurement

1. Output the 256QAM signal that has a voltage of 1 V_{pp} from the signal source.
2. Set this instrument as follows:

{MEAS SETUP}:	Meas Parameters	
	[Symbol Rate]	1000000
	[Modulation Format]	256QAM
	[Differential Code]	OFF
	[A/D Capture Length]	1500
	[Analysis Length]	1500
	[Burst Search]	OFF
	[Compensate Origin Offset]	ON
	[EVM Calculation Method]	RMS
	Synchronous Parameters	
	[Synchronization]	OFF
	Filter Parameters	
	[Meas Filter]	
	[Filter Type]	Sinc
	[Filter Parameter]	0.5
	[Filter Tap]	20
	[Ref Filter]	
	[Filter Type]	Nyquist
	[Filter Parameter]	0.5
	[Filter Tap]	20
	Average	
	[Average times]	OFF
	Equalizing Filter	OFF

7.2.2 IQ Input Test Signal Measurement

{INPUT}:	Input	Baseband(I&Q)
	Baseband Input	DC
	IQ Inverse	OFF
{TRIGGER}:	Trigger Source	Free Run

3. Press the **SINGLE** button on this unit to perform measurements.
4. Write the measurement results in the test data record sheet.

7.2.2.3 MSK Measurement

1. Output the MSK signal that has a voltage of 1 Vpp from the signal source.
2. Set this instrument as follows:

{MEAS SETUP}:	Meas Parameters		
	[Symbol Rate]	1000000	
	[Modulation Format]	MSK	
	[Differential Code]	OFF	
	[A/D Capture Length]	1500	
	[Analysis Length]	1500	
	[Burst Search]	OFF	
	[Compensate Origin Offset]	ON	
	[EVM Calculation Method]	RMS	
	Synchronous Parameters		
	[Synchronization]	OFF	
	Filter Parameters		
	[Meas Filter]		
	[Filter Type]	Sinc	
	[Filter Parameter]	0.5	
	[Filter Tap]	20	
	[Ref Filter]		
	[Filter Type]	Gauss	
	[Filter Parameter]	0.3	
	[Filter Tap]	20	
	Average		
	[Average times]	OFF	
	Equalizing Filter		
	[Equalizing Filter]	OFF	
	{INPUT}:	Input	Baseband(I&Q)
		Baseband Input	DC
		IQ Inverse	OFF

{TRIGGER}: **Trigger Source** Free Run

3. Press the **SINGLE** button on this unit to perform measurements.
4. Write the measurement results in the test data record sheet.

7.2.2.4 FSK Measurement

1. Output the FSK signal that has a voltage of 1 Vpp from the signal source.
2. Set this instrument as follows:

{MEAS SETUP}: **Meas Parameters**

[Symbol Rate]	1000000
[Modulation Format]	FSK
[Differential Code]	OFF
[A/D Capture Length]	1500
[Analysis Length]	1500
[Burst Search]	OFF
[Compensate Origin Offset]	ON

Synchronous Parameters

[Synchronization]	OFF
-------------------	-----

Filter Parameters

[Meas Filter]	
[Filter Type]	Sinc
[Filter Parameter]	0.5
[Filter Tap]	20
[Ref Filter]	
[Filter Type]	Gauss
[Filter Parameter]	0.5
[Filter Tap]	20

Average

[Average times]	OFF
-----------------	-----

Equalizing Filter

	OFF
--	-----

{INPUT}: **Input** Baseband(I&Q)

Baseband Input	DC
IQ Inverse	OFF

{TRIGGER}: **Trigger Source** Free Run

3. Press the **SINGLE** button on this unit to perform measurements.
4. Write the measurement results in the test data record sheet.

7.3 Test Data Record Sheet

7.3 Test Data Record Sheet

Test data record sheet

Model name:

Serial number:

7.3.1 RF Input

7.3.1.1 8PSK Signal

Test item	Specifications			Determination Pass / Fail
	Minimum value	Measured value	Maximum value	
Carrier frequency error	-20 Hz		20 Hz	
EVM (RMS)	None		2.0%rms	
Transmission power	-10.9 dBm		-9.1 dBm	

7.3.1.2 256QAM Signal

Test item	Specifications			Determination Pass / Fail
	Minimum value	Measured value	Maximum value	
Carrier frequency error	-20 Hz		20 Hz	
EVM (RMS)	None		2.0%rms	
Transmission power	-10.9 dBm		-9.1 dBm	

7.3.1.3 MSK Signal

Test item	Specifications			Determination Pass / Fail
	Minimum value	Measured value	Maximum value	
Carrier frequency error	-20 Hz		20 Hz	
EVM (RMS)	None		2.5%rms	
Transmission power	-10.9 dBm		-9.1 dBm	

7.3.1.4 FSK Signal

Test item	Specifications			Determination Pass / Fail
	Minimum value	Measured value	Maximum value	
Carrier frequency error	-200 Hz		200 Hz	
Max Deviation	130 kHz		190 kHz	
Transmission power	-10.9 dBm		-9.1 dBm	

7.3.2 IQ Input

7.3.2 IQ Input

7.3.2.1 8PSK Signal

Test item	Specifications			Determination Pass / Fail
	Minimum value	Measured value	Maximum value	
Carrier frequency error	-5 Hz		5 Hz	
EVM (RMS)	None		1.5%rms	

7.3.2.2 256QAM Signal

Test item	Specifications			Determination Pass / Fail
	Minimum value	Measured value	Maximum value	
Carrier frequency error	-5 Hz		5 Hz	
EVM (RMS)	None		1.5%rms	

7.3.2.3 MSK Signal

Test item	Specifications			Determination Pass / Fail
	Minimum value	Measured value	Maximum value	
Carrier frequency error	-5 Hz		5 Hz	
EVM (RMS)	None		2.0%rms	

7.3.2.4 FSK Signal

Test item	Specifications			Determination Pass / Fail
	Minimum value	Measured value	Maximum value	
Carrier frequency error	-50 Hz		50 Hz	
Max Deviation	130 kHz		190 kHz	

8. SPECIFICATIONS

8.1 Conditions

8.1.1 Instrument Conditions

Item	Specifications
Ambient temperature range	+20°C to +30°C
Input frequency range RF input	50 MHz to 6 GHz
Input level range RF input IQ input	For Preamp OFF After Auto Level Set is complete. <1 V _{pp}
Measurement Parameters Analysis Length Compensate Origin Offset EVM Calculation Method	1500 Symbol ON RMS
Filter Parameters Meas Filter Filter Type Filter Parameter Filter Tap	Sinc 0.5 20

8.1.2 Conditions of Signal to Be Measured

8.1.2 Conditions of Signal to Be Measured

Item	Specifications
Modulation format	8PSK, 256QAM, MSK, FSK
Carrier frequency error	0 Hz
EVM	0%rms
Level	
RF input	-10 dBm
IQ input	1 Vpp
Transmission filter	
8PSK, 256QAM	Nyquist, $\alpha=0.5$
MSK	Gauss, BT=0.3
FSK	Gauss, BT=0.5
Modulation index	
FSK	0.32

8.2 Single-Carrier General-Purpose Modulation Analysis Performance

8.2.1 RF Input

The reference frequency accuracy, frequency response, and calibration signal level accuracy depend on the specifications of the R3681 series. All specifications are specified after Auto Level Set is executed.

8.2.1.1 8PSK Signal

Item	Specifications
Carrier frequency error Measurement accuracy Symbol Rate 10 kHz to 5 MHz Symbol Rate 5 MHz to 20 MHz	$\leq \pm(\text{Reference frequency accuracy} \times \text{Carrier frequency} + 20) \text{ Hz}$ $\leq \pm(\text{Reference frequency accuracy} \times \text{Carrier frequency} + 50) \text{ Hz}$
EVM Residual EVM Symbol Rate 10 kHz to 300 kHz Symbol Rate 300 kHz to 5 MHz Symbol Rate 5 MHz to 20 MHz	$\leq 5.0\% \text{rms}$ $\leq 2.0\% \text{rms}$ $\leq 4.0\% \text{rms}$
Power measurement Accuracy Symbol Rate 10 kHz to 20 MHz	$\leq \pm(0.3 + \text{Frequency response} + \text{Calibration signal level accuracy}) \text{ dB}$

8.2.1 RF Input

8.2.1.2 256QAM Signal

Item	Specifications
Carrier frequency error Measurement accuracy Symbol Rate 10 kHz to 5 MHz Symbol Rate 5 MHz to 20 MHz	$\pm(\text{Reference frequency accuracy} \times \text{Carrier frequency} + 20)$ Hz $\pm(\text{Reference frequency accuracy} \times \text{Carrier frequency} + 50)$ Hz
EVM Residual EVM Symbol Rate 10 kHz to 300 kHz Symbol Rate 300 kHz to 5 MHz Symbol Rate 5 MHz to 20 MHz	$\leq 5.0\%$ rms $\leq 2.0\%$ rms $\leq 4.0\%$ rms
Power measurement Accuracy Symbol Rate 10 kHz to 20 MHz	$\pm(0.3 + \text{Frequency response} + \text{Calibration signal level accuracy})$ dB

8.2.1.3 MSK Signal

Item	Specifications
Carrier frequency error Measurement accuracy Symbol Rate 10 kHz to 5 MHz Symbol Rate 5 MHz to 20 MHz	$\pm(\text{Reference frequency accuracy} \times \text{Carrier frequency} + 20)$ Hz $\pm(\text{Reference frequency accuracy} \times \text{Carrier frequency} + 50)$ Hz
EVM Residual EVM Symbol Rate 10 kHz to 300 kHz Symbol Rate 300 kHz to 5 MHz Symbol Rate 5 MHz to 20 MHz	$\leq 5.0\%$ rms $\leq 2.5\%$ rms $\leq 4.5\%$ rms
Power measurement Accuracy Symbol Rate 10 kHz to 20 MHz	$\pm(0.3 + \text{Frequency response} + \text{Calibration signal level accuracy})$ dB

8.2.1.4 FSK Signal

Item	Specifications
Carrier frequency error Measurement accuracy Symbol Rate 10 kHz to 40 kHz Symbol Rate 40 kHz to 20 MHz	$<\pm(\text{Reference frequency accuracy} \times \text{Carrier frequency} + 8) \text{ Hz}$ $<\pm(\text{Reference frequency accuracy} \times \text{Carrier frequency} + 2.0 \times 10^{-4} \times \text{Symbol Rate}) \text{ Hz}$
Max Deviation Measurement accuracy Symbol Rate 10 kHz to 20 MHz	$<\pm (0.03 \times \text{Symbol Rate}) \text{ Hz}$
Power measurement Accuracy Symbol Rate 10 kHz to 20 MHz	$<\pm(0.3 + \text{Frequency response} + \text{Calibration signal level accuracy}) \text{ dB}$

8.2.2 IQ Input

8.2.2 IQ Input

8.2.2.1 8PSK Signal

Item	Specifications
Carrier frequency error Measurement accuracy Symbol Rate 10 kHz to 20 MHz	$<\pm 5$ Hz
EVM Residual EVM Symbol Rate 10 kHz to 20 MHz	$<1.5\%$ rms

8.2.2.2 256QAM Signal

Item	Specifications
Carrier frequency error Measurement accuracy Symbol Rate 10 kHz to 20 MHz	$<\pm 5$ Hz
EVM Residual EVM Symbol Rate 10 kHz to 20 MHz	$<1.5\%$ rms

8.2.2.3 MSK Signal

Item	Specifications
Carrier frequency error Measurement accuracy Symbol Rate 10 kHz to 20 MHz	$<\pm 5$ Hz
EVM Residual EVM Symbol Rate 10 kHz to 20 MHz	$<2.0\%$ rms

8.2.2.4 FSK Signal

Item	Specifications
Carrier frequency error	
Measurement accuracy	
Symbol Rate 10 kHz to 100 kHz	$<\pm 5$ Hz
Symbol Rate 100 kHz to 20 MHz	$<\pm(5.0 \times 10^{-5} \times \text{Symbol Rate})$ Hz
Max Deviation	
Measurement accuracy	
Symbol Rate 10 kHz to 20 MHz	$<\pm(0.03 \times \text{Symbol Rate})$ Hz

APPENDIX

This section describes the following supplemental information.

- A.1 Technical Notes
- A.2 Error Message List
- A.3 Warning Message List

A.1 Technical Notes

A.1.1 How to Calculate Measurement Values

EVM, Mag Error, and Phase Error are calculated by using the following equation after the frequency error, magnitude, origin offset (when Compensate Origin Offset is set to ON), and droop are corrected.

Error Vector Magnitude (EVM)

EVM is defined by Figure A-1 and calculated by using the following equations.

When EVM Calculate Method is set to RMS:

$$EVM = \sqrt{\frac{\sum_i^K \{ (Im(i) - Ir(i))^2 + (Qm(i) - Qr(i))^2 \}}{\sum_i^K \{ Ir(i)^2 + Qr(i)^2 \}}} \times 100 [\%]$$

When EVM Calculate Method is set to Max:

$$EVM = \sqrt{\frac{\left[\sum_i^K \{ (Im(i) - Ir(i))^2 + (Qm(i) - Qr(i))^2 \} \right] / K}{\text{Max} \{ Ir(i)^2 + Qr(i)^2 \}}} \times 100 [\%]$$

- $Im(i), Qm(i)$: Measurement value
- $Ir(i), Qr(i)$: Reference value
- i : Symbol number
- K : Measurement length

A.1.1 How to Calculate Measurement Values

Mag Error

Mag Error is defined by Figure A-1 and calculated by using the following equation.

When EVM Calculate Method is set to RMS:

$$MagError = \sqrt{\frac{\sum_i^K \left\{ \sqrt{Im(i)^2 + Qm(i)^2} - \sqrt{Ir(i)^2 + Qr(i)^2} \right\}}{\sum_i^K \left\{ Ir(i)^2 + Qr(i)^2 \right\}}} \times 100 \text{ [%]}$$

When EVM Calculate Method is set to Max:

$$MagError = \sqrt{\frac{\left[\sum_i^K \left\{ \sqrt{Im(i)^2 + Qm(i)^2} - \sqrt{Ir(i)^2 + Qr(i)^2} \right\} \right] / K}{Max\{Ir(i)^2 + Qr(i)^2\}}} \times 100 \text{ [%]}$$

- Im(i), Qm(i)*: Measurement value
- Ir(i), Qr(i)*: Reference value
- i*: Symbol number
- K*: Measurement length

Phase Error

Phase Error is defined by Figure A-1 and calculated by using the following equation.

$$PhaseError = \sqrt{\frac{\sum_i^K \left\{ \tan^{-1}(Qm(i)/Im(i)) - \tan^{-1}(Qr(i)/Ir(i)) \right\}^2}{K}} \times 180 / \pi \text{ [deg]}$$

- Im(i), Qm(i)*: Measurement value
- Ir(i), Qr(i)*: Reference value
- i*: Chip number
- K*: Measurement length




Figure A-1 Error Vector Magnitude, Magnitude Error, Phase Error

A.1.2 Symbol Mapping

A.1.2 Symbol Mapping

The mapping of each Modulation Format is shown in the following. When Differential Code is set to ON, the mapping shows the amount of phase variation. The MSB is shown at the left in the mapping and LSB is shown at the right.

MEMO: Because Demodulated Data of Window Format is displayed from the LSB, the left and right of the display are reversed to the mapping bit display.

A.1.2.1 BPSK




Figure A-2 BPSK Mapping

A.1.2.2 QPSK($\pi/4$ DQPSK)




Figure A-3 QPSK Mapping

The phase of 00 is 0 degree in Differential. The phase of 00 is 45 degrees in $\pi/4$ DQPSK.

A.1.2.3 8PSK




Figure A-4 8PSK Mapping

A.1.2.4 16QAM (Differential Code OFF)




Figure A-5 16QAM Mapping (Differential Code OFF)

A.1.2 Symbol Mapping

A.1.2.5 16QAM (Differential Code ON)




Figure A-6 16QAM Mapping (Differential Code ON)

A quadrant is coded by using the following equations in which A_k represents MSB and B_k represents MSB-1.

$$I_k = (\overline{A_k \oplus B_k}) \cdot (A_k \oplus I_{k-1}) + (A_k \oplus B_k) \cdot (A_k \oplus Q_{k-1})$$

$$Q_k = (\overline{A_k \oplus B_k}) \cdot (B_k \oplus Q_{k-1}) + (A_k \oplus B_k) \cdot (B_k \oplus I_{k-1})$$

The above equations are also used for the following QAM signals.

A.1.2.6 32QAM (Differential Code OFF)




Figure A-7 32QAM Mapping (Differential Code OFF)

A.1.2.7 32QAM (Differential Code ON)




Figure A-8 32QAM Mapping (Differential Code ON)

A.1.2 Symbol Mapping

A.1.2.8 64QAM (Differential Code OFF)




Figure A-9 64QAM Mapping (Differential Code OFF)

A.1.2.9 64QAM (Differential Code ON)




Figure A-10 64QAM Mapping (Differential Code ON)

A.1.2.10 128QAM (Differential Code OFF)




Figure A-11 128QAM Mapping (Differential Code OFF)

Figure A-11 shows the mapping of the Bit value, which excludes MSB and MSB-1, in the first quadrant. Each Bit value mapping in the second, third, and fourth quadrants rotates by 90, 180, and 270 degrees respectively with respect to the Bit value mapping in the first quadrant. The values of MSB and MSB-1 are represented by $IkQk$ and each symbol is represented by 7 bits.

A.1.2 Symbol Mapping

A.1.2.11 128QAM (Differential Code ON)




Figure A-12 128QAM Mapping (Differential Code ON)

A.1.2.12 256QAM (Differential Code OFF)




Figure A-13 125QAM Mapping (Differential Code OFF)

Figure A-13 shows the mapping of the Bit value, which excludes MSB and MSB-1, in the first quadrant. Each Bit value mapping in the second, third, and fourth quadrants rotates by 90, 180, and 270 degrees respectively with respect to the Bit value mapping in the first quadrant. The values of MSB and MSB-1 are represented by $IkQk$ and each symbol is represented by 8 bits.

A.1.2 Symbol Mapping

A.1.2.13 256QAM (Differential Code ON)




Figure A-14 256QAM Mapping (Differential Code ON)

A.1.2.14 MSK, FSK

Table A-1 MSK and FSK Mapping

Bit value	0	1
Frequency	+	-

The Differential coding is performed according to the following equation.

$$\hat{d}_i = d_i \oplus d_{i-1} \quad \text{where } \oplus \text{ denotes modulo 2 addition.}$$

A.1.3 Synchronous Word Setting

Synchronous Word is set by writing it from the LSB and converting it to hexadecimal in units of 8 bits. If a unit contains less than 8 bits, zeros are added at the end.

For example, GSM TSC0 is shown below. The Synchronous Word in GSM TSC0 is provided as shown below.

00100101110000100010010111(26 bit)

Delimit this by units of 8 bits and convert it to hexadecimal.

25 C2 25 C0

The Synchronous Offset in GSM is 61 symbols. After these settings are complete, the Synchronous Parameters Setup dialog box is shown below.




Figure A-15 Synchronous Parameters Setup Dialog Box

A.1.4 Cutoff of Filter Type Sinc

A.1.4 Cutoff of Filter Type Sinc

The cutoff is set in Filter Parameter when Filter Type is set to Sinc. Set the cutoff by the ratio of the cutoff frequency to the Nyquist frequency that is used when Oversampling is set to 4 in any modulation format except for FSK and is set to 8 in FSK. Figure A-16 shows examples of the power spectrum measured under the following conditions: Symbol rate; 1 MHz, QPSK signal, Meas Filter; Sinc filter, and Filter Parameter; 1.0, 0.75, and 0.5




Figure A-16 QPSK Signal Power Spectrum for each Cutoff

For the Nyquist frequency of 2 MHz, each spectrum is analyzed by using the filters that have cutoff frequencies of 2 MHz, 1.5 MHz, and 1 MHz. If adjacent channels or noise are close to the signal to be measured, reduce the cutoff to prevent the modulation accuracy from deteriorating and measure the signal. The longer the Tap size of the filter, the sharper the cutoff characteristic and the more accurate the modulation accuracy.

A.1.5 Tx Power and Peak Power in Total Result

Tx Power and Peak Power displayed in Total Result are measurement results of power through Meas Filter. For example, when Meas Filter is set to the Root Nyquist filter ($\alpha = 0.22$), the displayed Tx Power is lower by 0.24 dB than the actual transmission power.

A.1.6 A/D Capture Length and Analysis Length

The number of symbols of A/D data acquired into memory is set in A/D Capture Length. The number of symbols of data to be actually analyzed is set in Analysis Length. The A/D data acquired in the memory is searched for the burst signal or Synchronous Word in the burst signal analysis or synchronous analysis by using Synchronous Word.

When the burst signal is measured, the burst signal must be included in the acquired A/D data. When the TDMA signal is measured, A/D Capture Length must be set to 2-frame length. As a concrete example, the GSM signal measurement is shown below. The GSM signal includes 1250 symbols in one frame. When 1-slot communication signal exists in one frame, A/D Capture Length must be set to 2500 because 2-frame A/D data must be acquired to acquire the 1-slot communication signal surely in the A/D memory. Figure A-17 shows an example of acquiring the burst signal into the A/D memory.




Figure A-17 Example of Acquiring the Burst Signal into the A/D Memory

When a signal is measured by synchronizing with Synchronous Word, Synchronous Word must be included in the acquired A/D data. Set A/D Capture Length to 2-frame length as when measuring the burst signal.

When a CW signal is measured by not synchronizing with Synchronous Word, set the same value to both A/D Capture Length and Analysis Length.

A.1.7 Standard Setting parameter

A.1.7 Standard Setting parameter

Table A-2 shows each standard setting parameter that can be set by touching the **Standard** key.

Table A-2 Standard Setting Parameter

Standard	Symbol Rate	Modulation Format	Differential Code	A/D Capture Length	Analysis Length
PDC	21 k	$\pi/4$ DQPSK	ON	400	135
GSM	270.833 k	MSK	ON	2500	148
PHS (PHP)	192 k	$\pi/4$ DQPSK	ON	1100	111
DECT	1152 k	FSK	OFF	11200	424
CDPD	19.2 k	MSK	OFF	378	378
TETRA	18 k	$\pi/4$ DQPSK	ON	1300	231
DVB-C	5.274 M	64QAM	ON	1088	1088
Bluetooth	1 M	FSK	OFF	1464	366

Standard	Burst Search	Search Threshold	Amplitude Synchronization	Analysis Start Offset	Compensate Orgin Offset	EVM Calculation Method
PDC	ON	-20	ON	---	ON	RMS
GSM	ON	-20	ON	---	OFF	RMS
PHS (PHP)	ON	-20	ON	---	ON	RMS
DECT	ON	-20	ON	---	OFF	RMS
CDPD	OFF	---	---	---	ON	RMS
TETRA	ON	-20	ON	---	ON	RMS
DVB-C	OFF	---	---	---	ON	MAX
Bluetooth	ON	-20	ON	---	OFF	RMS

Standard	Meas Filter Type	Meas Filter Parameter	Meas Filter Tap	Ref Filter Type	Ref Filter Parameter	Ref Filter Tap
PDC	Root Nyquist	0.5	8	Nyquist	0.5	8
GSM	Sinc	0.5	8	Gauss	0.3	8
PHS (PHP)	Root Nyquist	0.5	8	Nyquist	0.5	8
DECT	Sinc	0.5	8	Gauss	0.5	8
CDPD	Sinc	0.75	8	Gauss	0.5	8
TETRA	Root Nyquist	0.35	8	Nyquist	0.35	8
DVB-C	Root Nyquist	0.13	20	Nyquist	0.13	20
Bluetooth	Sinc	0.5	8	Gauss	0.5	8

A.1.8 File Format of the User Filter

Create the user filter by setting Oversampling to 4 when Modulation Format is set to any format except for FSK, and by setting Oversampling to 8 when Modulation Format is set to FSK. Set the number of data points to “the number of filter symbols \times Oversampling + 1”.

The ASCII format is used as the file format and LF is used as the data delimiter.

An example of the user filter (10 symbols)

```
2.70472e-034
-3.75317e-005
1.7917e-019
0.000402921
-7.83731e-019
-0.00140999
1.97597e-018
0.0035743
-3.91292e-018
-0.00768832
6.62645e-018
0.0149294
-9.93553e-018
-0.0272815
1.34316e-017
0.0492443
-1.65511e-017
-0.0968188
1.87148e-017
0.315094
0.499983
0.315094
1.87148e-017
-0.0968188
-1.65511e-017
0.0492443
1.34316e-017
-0.0272815
-9.93553e-018
0.0149294
```

A.1.8 File Format of the User Filter

6.62645e-018
-0.00768832
-3.91292e-018
0.0035743
1.97597e-018
-0.00140999
-7.83731e-019
0.000402921
1.7917e-019
-3.75317e-005
2.70472e-034

Create the file with extension “.flt”.

A.1.9 Demodulated Data Saving Function

```
1,0,1,****
2,1,0,Sync
3,1,0,Sync
4,1,0,Sync
5,1,1,Sync
6,1,1,Sync
7,0,0,Sync
8,1,1,Sync
9,0,1,Sync
10,0,0,****
11,0,0,****
12,1,0,****
13,1,0,****
14,0,1,****
15,1,1,****
:
```

A.2 Error Message List

This section describes error messages displayed on this instrument.

The following information is included.

- Error number
- Displayed message
- Cause of the error and action to be taken

Table A-3 Error Message List

Error number	Displayed message	Description
-1250	No such file or directory.	The file or directory does not exist. Check the file name or directory name.
-1251	Permission denied.	File operation is forbidden. Check the drive name, file name, or directory name.
-1252	Not enough space on the disk.	Not enough space is available. Delete all unnecessary files.
-1253	File read/write error.	A file I/O error occurred. Check if there is sufficient disk space or the disk is write-protected.
-1300	Device is not ready.	No disk is inserted.
-1500	Option required.	The appropriate option function is required.
-3210	Input Level is out of range. Check the Ref. Level.	The input signal level is outside the permitted range. Check the reference level or input signal level.
-3211	Auto Level Set cannot be succeed. Signal level is not stable.	Auto Level Set is not complete. Check to see if the input signal level is not constant or if the attenuator is set to manual
-3228	Not available in I/Q input mode.	Cannot be set when the Baseband input is specified.
-3242	Cannot find out Burst.	Burst cannot be detected in A/D data.
-3264	Wrong data size.	The data size is not correct.
-3265	Empty user filter.	No user filter data is loaded.

A.3 Warning Message List

A.3 Warning Message List

This section describes the warning messages displayed on this instrument.

The following information is included.

- Displayed message
- Description

Table A-4 Warning Message List

Displayed message	Description
The result is not corresponding to the setting.	This message is displayed when Modulation Format is set to FSK while the graph, on which the results cannot be displayed when Modulation Format is set to FSK, is displayed.
Equalizing Filter is void.	This message is displayed when Equalizing Filter cannot be used (when Transmission Mag/Phase Characteristics graph is displayed).
Some settings are changed. Do you execute it?	This message is displayed when the Standard setting is changed.
The scale setting is changed. Do you execute it?	This message is displayed when the Marker Interlock function and the Scale Interlock function are followed.

ALPHABETICAL INDEX

[Symbol]			
[A/D Capture Length]	5-4, 5-5	[Transmission Phase Characteristics]	5-10, 5-12
[Amplitude Synchronization]	5-4, 5-6	[User Filter Tap]	5-4, 5-7
[Analysis Length]	5-4, 5-5	[vs Symbol Graph]	5-10, 5-12
[Analysis Start Offset]	5-4, 5-6	{DISPLAY}	5-10
[Baseband Input]	5-15	{FREQ}	5-18
[Burst Search]	5-4, 5-5	{INPUT}	5-15
[Compensate Origin Offset]	5-4, 5-6	{LEVEL}	5-17
[Constellation]	5-10, 5-11, 5-12	{MEAS MODE}	5-4
[Demodulated Data]	5-10, 5-11	{MEAS SETUP}	5-4
[Differential Code]	5-4, 5-5	{MKR}	5-14
[EVM Calculation Method]	5-4, 5-6	{SCALE}	5-13
[EVM Spectrum]	5-10	{TRIGGER}	5-16
[EVM vs Symbol]	5-10		
[Filter Parameter]	5-4, 5-7	[Numerics]	
[Filter Tap]	5-4, 5-7	128QAM (Differential Code OFF)	A-9
[Filter Type]	5-4, 5-6, 5-7	128QAM (Differential Code ON)	A-10
[Frequency Eye Diagram]	5-10, 5-11	16QAM (Differential Code OFF)	A-5
[Frequency vs Symbol]	5-10, 5-11	16QAM (Differential Code ON)	A-6
[I Eye Diagram]	5-10, 5-11	256QAM (Differential Code OFF)	A-11
[Input]	5-15	256QAM (Differential Code ON)	A-12
[IQ Inverse]	5-15	256QAM Measurement	7-4, 7-9
[Line]	5-10, 5-12	256QAM Signal	7-12, 7-14, 8-4, 8-6
[Load File]	5-4, 5-6, 5-7	32QAM (Differential Code OFF)	A-7
[Load Meas Filter]	5-4, 5-6	32QAM (Differential Code ON)	A-7
[Load Ref Filter]	5-4, 5-7	64QAM (Differential Code OFF)	A-8
[Mag Error Spectrum]	5-10	64QAM (Differential Code ON)	A-8
[Mag Error vs Symbol]	5-10	8PSK	A-5
[Meas Filter]	5-4, 5-6	8PSK Measurement	7-3, 7-8
[Modulation Format]	5-4, 5-5	8PSK Signal	7-12, 7-14, 8-3, 8-6
[Phase Error Spectrum]	5-10		
[Phase Error vs Symbol]	5-10	[A]	
[Phase vs Symbol]	5-10, 5-11	A/D Capture Length and Analysis	
[Power Spectrum]	5-10	Length	A-15
[Power vs Symbol]	5-10	Analysis Restart	5-4, 5-5
[Q Eye Diagram]	5-10, 5-11	APPENDIX	A-1
[Ref Filter]	5-4, 5-7	ATT	5-17
[Search Threshold]	5-4, 5-5	Auto Level Set	5-17
[Symbol]	5-10, 5-12	Auto Scale	5-13
[Symbol Rate]	5-4, 5-5	Average	5-4, 5-8
[Synchronization]	5-4, 5-6	Average Peak Type	5-4, 5-8
[Synchronous Length]	5-4, 5-6	Average times	5-4, 5-8
[Synchronous Offset]	5-4, 5-6		
[Synchronous Word]	5-4, 5-6	[B]	
[Total Result]	5-10, 5-11	BEFORE OPERATING	2-1
[Trace]	5-10, 5-12	Before Turning On	2-3
[Trace & Symbol]	5-10, 5-12	Bluetooth	5-4, 5-8
[Transmission Mag Characteristics]	5-10, 5-12	BPSK	A-4

Alphabetical Index

[C]

CDPD 5-4, 5-8
 Center 5-18
 Channel Number 5-18
 Check the Supply Power 3-5
 Command Reference Format 6-1
 Common Commands 6-3
 Conditions 8-1
 Conditions of Signal to Be Measured 8-2
 Connecting Accessories 3-4
 Connecting the Keyboard and Mouse 3-4
 Connecting the Power Cable 3-5
 Conventions of Notation Used
 in This Document 1-3
 Cutoff of Filter Type Sinc A-14

[D]

DECT 5-4, 5-8
 Delta Marker 5-14
 Demodulated Data Saving Function A-19
 Description of the Function of Each Key 5-4
 Display Type 5-10, 5-12
 Dual Display 5-10, 5-12
 DVB-C 5-4, 5-8

[E]

Electromagnetic Interference 2-3
 Equalizing Filter 5-4, 5-9
 Error Message List A-21
 EVM Measurement of the DUT
 by Using the Equalizing Filter 4-6
 Ext1 5-16
 Ext2 5-16

[F]

File Format of the User Filter A-17
 Filter Parameters 5-4, 5-6
 Free Run 5-16
 Freq Offset 5-18
 FSK A-12
 FSK Measurement 7-6, 7-11
 FSK Signal 7-13, 7-14,
 8-5, 8-7
 Function Bar 5-3
 FUNCTIONAL EXPLANATION 5-1

[G]

Getting the Software Running
 with Stability 2-2
 GSM 5-4, 5-7

[H]

Handling the Touch Screen 2-2
 Hard Disk Drive 2-1
 How to Calculate Measurement Values .. A-1

[I]

If a Fault Should Occur 2-1
 IF Power 5-16
 Input Setup 5-15
 Instrument Conditions 8-1
 INTRODUCTION 1-1
 IQ Input 7-14, 8-6
 IQ Input Test Signal Measurement 7-8

[L]

Limitations Imposed when Using
 Windows XP 2-5
 Link 5-16
 List of Commands 6-4
 Locating This Instrument 3-2

[M]

Make Equalizer 5-4, 5-8
 Marker 5-14
 Marker Interlock 5-14
 Marker OFF 5-14
 Meas Parameters 5-4, 5-5
 MEASUREMENT EXAMPLES 4-1
 Measurement Tool Bar 5-19
 Menu Index 5-1
 MENU MAP 5-1
 Min ATT 5-17
 Modulation Accuracy Measurement
 of the QPSK Signal 4-1
 MSK A-12
 MSK Measurement 7-5, 7-10
 MSK Signal 7-12, 7-14,
 8-4, 8-6

[O]

Operating Environment 3-2
 Operation Check 3-7
 Other Manuals Relating to
 This Instrument 1-2
 Outline of This Manual 1-1
 Overcurrent Protection 2-1

[P]

PDC 5-4, 5-7
 Peak Search 5-14

PERFORMANCE VERIFICATION	7-1	Symbol Mapping	A-4
PHS	5-4, 5-8	Symbol Start	5-13
Preamplifier On/Off	5-17	Symbol Stop	5-13
Prevention of Electrostatic Buildup	3-3	Synchronous Parameters	5-4, 5-6
Product Overview	1-2	Synchronous Word Setting	A-13
[Q]		[T]	
QPSK($\pi/4$ DQPSK)	A-4	Technical Notes	A-1
Quad Display	5-10, 5-12	Test Data Record Sheet	7-12
[R]		Test Procedures	7-3
Ref Level	5-17	Test Signal Specifications	7-1
Ref Offset	5-17	TETRA	5-4, 5-8
Refresh Cycle	5-4, 5-8	Trademarks	1-4
Registered Trademarks	1-4	Transporting	2-2
Removing and Attaching the Front Panel	2-3	Trigger Delay	5-16
Removing the Case	2-1	Trigger Slope	5-16
Return	5-4, 5-6, 5-7, 5-8, 5-12, 5-16	Trigger Source	5-16
RF Input	7-12, 8-3	Tx Power and Peak Power in Total Result	A-14
RF Input Test Signal Measurement	7-3	[U]	
[S]		Unpacking Inspection	3-1
Save Demod Data	5-10, 5-12	[W]	
Scale Interlock	5-13	Warning Message List	A-22
SCPI COMMAND REFERENCE	6-1	Window Format	5-10
SETUP	3-1	[X]	
Single Display	5-10, 5-12	X Scale Left	5-13
Single-Carrier General-Purpose Modulation Analysis Performance	8-3	X Scale Right	5-13
Soft Menu Bar	5-3	[Y]	
SPECIFICATIONS	8-1	Y Scale Lower	5-13
Standard	5-4, 5-7	Y Scale Upper	5-13
Standard Setting parameter	A-16		
Status Register	6-17		
Subsystem-CALCulate	6-7		
Subsystem-DISPlay	6-8		
Subsystem-FETCh	6-14		
Subsystem-FORMat	6-16		
Subsystem-HCOpy	6-16		
Subsystem-INITiate	6-7		
Subsystem-INPut	6-4		
Subsystem-MEASure	6-9		
Subsystem-MMEMory	6-9		
Subsystem-READ	6-12		
Subsystem-SENSe	6-5		
Subsystem-STATus	6-16		
Subsystem-SYSTem	6-4		
Subsystem-TRIGger	6-7		
Supply Description	3-5		
Switching Communication Systems	5-3		

IMPORTANT INFORMATION FOR ADVANTEST SOFTWARE

PLEASE READ CAREFULLY: This is an important notice for the software defined herein. Computer programs including any additions, modifications and updates thereof, operation manuals, and related materials provided by Advantest (hereafter referred to as "SOFTWARE"), included in or used with hardware produced by Advantest (hereafter referred to as "PRODUCTS").

SOFTWARE License

All rights in and to the SOFTWARE (including, but not limited to, copyright) shall be and remain vested in Advantest. Advantest hereby grants you a license to use the SOFTWARE only on or with Advantest PRODUCTS.

Restrictions

- (1) You may not use the SOFTWARE for any purpose other than for the use of the PRODUCTS.
- (2) You may not copy, modify, or change, all or any part of, the SOFTWARE without permission from Advantest.
- (3) You may not reverse engineer, de-compile, or disassemble, all or any part of, the SOFTWARE.

Liability

Advantest shall have no liability (1) for any PRODUCT failures, which may arise out of any misuse (misuse is deemed to be use of the SOFTWARE for purposes other than its intended use) of the SOFTWARE. (2) For any dispute between you and any third party for any reason whatsoever including, but not limited to, infringement of intellectual property rights.

LIMITED WARRANTY

1. Unless otherwise specifically agreed by Seller and Purchaser in writing, Advantest will warrant to the Purchaser that during the Warranty Period this Product (other than consumables included in the Product) will be free from defects in material and workmanship and shall conform to the specifications set forth in this Operation Manual.
2. The warranty period for the Product (the "Warranty Period") will be a period of one year commencing on the delivery date of the Product.
3. If the Product is found to be defective during the Warranty Period, Advantest will, at its option and in its sole and absolute discretion, either (a) repair the defective Product or part or component thereof or (b) replace the defective Product or part or component thereof, in either case at Advantest's sole cost and expense.
4. This limited warranty will not apply to defects or damage to the Product or any part or component thereof resulting from any of the following:
 - (a) any modifications, maintenance or repairs other than modifications, maintenance or repairs (i) performed by Advantest or (ii) specifically recommended or authorized by Advantest and performed in accordance with Advantest's instructions;
 - (b) any improper or inadequate handling, carriage or storage of the Product by the Purchaser or any third party (other than Advantest or its agents);
 - (c) use of the Product under operating conditions or environments different than those specified in the Operation Manual or recommended by Advantest, including, without limitation, (i) instances where the Product has been subjected to physical stress or electrical voltage exceeding the permissible range and (ii) instances where the corrosion of electrical circuits or other deterioration was accelerated by exposure to corrosive gases or dusty environments;
 - (d) use of the Product in connection with software, interfaces, products or parts other than software, interfaces, products or parts supplied or recommended by Advantest;
 - (e) incorporation in the Product of any parts or components (i) provided by Purchaser or (ii) provided by a third party at the request or direction of Purchaser or due to specifications or designs supplied by Purchaser (including, without limitation, any degradation in performance of such parts or components);
 - (f) Advantest's incorporation or use of any specifications or designs supplied by Purchaser;
 - (g) the occurrence of an event of force majeure, including, without limitation, fire, explosion, geological change, storm, flood, earthquake, tidal wave, lightning or act of war; or
 - (h) any negligent act or omission of the Purchaser or any third party other than Advantest.
5. **EXCEPT TO THE EXTENT EXPRESSLY PROVIDED HEREIN, ADVANTEST HEREBY EXPRESSLY DISCLAIMS, AND THE PURCHASER HEREBY WAIVES, ALL WARRANTIES, WHETHER EXPRESS OR IMPLIED, STATUTORY OR OTHERWISE, INCLUDING, WITHOUT LIMITATION, (A) ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE AND (B) ANY WARRANTY OR REPRESENTATION AS TO THE VALIDITY, SCOPE, EFFECTIVENESS OR USEFULNESS OF ANY TECHNOLOGY OR ANY INVENTION.**
6. **THE REMEDY SET FORTH HEREIN SHALL BE THE SOLE AND EXCLUSIVE REMEDY OF THE PURCHASER FOR BREACH OF WARRANTY WITH RESPECT TO THE PRODUCT.**
7. **ADVANTEST WILL NOT HAVE ANY LIABILITY TO THE PURCHASER FOR ANY INDIRECT, INCIDENTAL, SPECIAL, CONSEQUENTIAL OR PUNITIVE DAMAGES, INCLUDING, WITHOUT LIMITATION, LOSS OF ANTICIPATED PROFITS OR REVENUES, IN ANY AND ALL CIRCUMSTANCES, EVEN IF ADVANTEST HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES AND WHETHER ARISING OUT OF BREACH OF CONTRACT, WARRANTY, TORT (INCLUDING, WITHOUT LIMITATION, NEGLIGENCE), STRICT LIABILITY, INDEMNITY, CONTRIBUTION OR OTHERWISE. TORT (INCLUDING, WITHOUT LIMITATION, NEGLIGENCE), STRICT LIABILITY, INDEMNITY, CONTRIBUTION OR OTHERWISE.**
8. **OTHER THAN THE REMEDY FOR THE BREACH OF WARRANTY SET FORTH HEREIN, ADVANTEST SHALL NOT BE LIABLE FOR, AND HEREBY DISCLAIMS TO THE FULLEST EXTENT PERMITTED BY LAW ANY LIABILITY FOR, DAMAGES FOR PRODUCT FAILURE OR DEFECT, WHETHER ARISING OUT OF BREACH OF CONTRACT, TORT (INCLUDING, WITHOUT LIMITATION, NEGLIGENCE), STRICT LIABILITY, INDEMNITY, CONTRIBUTION OR OTHERWISE.**

CUSTOMER SERVICE DESCRIPTION

In order to maintain safe and trouble-free operation of the Product and to prevent the incurrence of unnecessary costs and expenses, Advantest recommends a regular preventive maintenance program under its maintenance agreement.

Advantest's maintenance agreement provides the Purchaser on-site and off-site maintenance, parts, maintenance machinery, regular inspections, and telephone support and will last a maximum of ten years from the date the delivery of the Product. For specific details of the services provided under the maintenance agreement, please contact the nearest Advantest office listed at the end of this Operation Manual or Advantest's sales representatives.

Some of the components and parts of this Product have a limited operating life (such as, electrical and mechanical parts, fan motors, unit power supply, etc.). Accordingly, these components and parts will have to be replaced on a periodic basis. If the operating life of a component or part has expired and such component or part has not been replaced, there is a possibility that the Product will not perform properly. Additionally, if the operating life of a component or part has expired and continued use of such component or part damages the Product, the Product may not be repairable. Please contact the nearest Advantest office listed at the end of this Operation Manual or Advantest's sales representatives to determine the operating life of a specific component or part, as the operating life may vary depending on various factors such as operating condition and usage environment.

SALES & SUPPORT OFFICES

Advantest Korea Co., Ltd.

22BF, Kyobo KangNam Tower,
1303-22, Seocho-Dong, Seocho-Ku, Seoul #137-070, Korea
Phone: +82-2-532-7071
Fax: +82-2-532-7132

Advantest (Suzhou) Co., Ltd.

Shanghai Branch Office:
Bldg. 6D, NO.1188 Gumei Road, Shanghai, China 201102 P.R.C.
Phone: +86-21-6485-2725
Fax: +86-21-6485-2726

Shanghai Branch Office:
406/F, Ying Building, Quantum Plaza, No. 23 Zhi Chun Road,
Hai Dian District, Beijing,
China 100083
Phone: +86-10-8235-3377
Fax: +86-10-8235-6717

Advantest (Singapore) Pte. Ltd.

438A Alexandra Road, #08-03/06
Alexandra Technopark Singapore 119967
Phone: +65-6274-3100
Fax: +65-6274-4055

Advantest America, Inc.

3201 Scott Boulevard, Suite, Santa Clara, CA 95054, U.S.A
Phone: +1-408-988-7700
Fax: +1-408-987-0691

ROHDE & SCHWARZ Europe GmbH

Mühldorfstraße 15 D-81671 München, Germany
(P.O.B. 80 14 60 D-81614 München, Germany)
Phone: +49-89-4129-13711
Fax: +49-89-4129-13723

ADVANTEST[®]

<http://www.advantest.co.jp>