

---

---

**ADVANTEST®**

**ADVANTEST CORPORATION**

---

ANT\_Para Application Software Operation Manual

---

Applicable measuring instruments:  
R3755A/R3760

©2011 ADVANTEST CORPORATION  
*All rights reserved.*

First printing Jan.12, 2011  
Printed in Japan

---

---

**Revision History**

---

Revision	Revision date	Revised content	Total pages
1	12/Jan/2011	First creation	24
2	16/Sep/2011	External trigger	24
3	02/Nov/2012	R3755A Smith chart display LCR measurement	25




## TABLE OF CONTENTS

---

1. Purpose and Configuration .....	4
2. Application Software .....	5
3. Measurement Condition File .....	6
3.1. Setting Measurement Condition File .....	7
3.2. Setting Measurement Conditions, Measurement Items, and Limits for Each CH..	10
4. Connecting ANT_Para Application Software to R3760.....	16
4.1. ANT_Para Application Software Measurement Window.....	17
4.2. Setting Tab .....	18
4.3. Measure Tab .....	18
4.4. Lot Tab .....	19
4.5. Starting Test .....	22
4.6. Setup Menu .....	23
4.7. Closing ANT_Para .....	24
4.8. Measurement Result Format .....	25

## 1. Purpose and Configuration

By installing the network analyzer (R3755A/R3760) into a personal computer (PC), and combining the R3755A/R3760 with A170009 (SP4T) extension SW-BOX (4-port adapter for Antenna VSWR measurement), a maximum of four antenna elements can be measured. In this configuration, antenna characteristics are measured using the ANT\_Para application software and the result is saved to a file.



## 2. Application Software

Execute installation according to the CD-ROM manual included with the R3755A/R3760. The ANT\_Para application software operates by reading measurement conditions from a measurement condition file (Excel CSV file). As for measurement condition settings, when the ANT\_Para application software is installed, the measurement condition file is also installed as a sample. The following describes the measurement condition file.

### 3. Measurement Condition File

The following are example descriptions in an Excel file. (ANT\_Para sets measurement conditions by reading a file saved in CSV file format.)

	A	B	C	D	E	F	G	H	I	J	K	L	M	N	
1	Application Name	ANT_Para													
2	CSV Sheet Revision		3												
3	Product Name	R3760													
4	DAL Data File Save/Recall	DN													
5	DAL Type (Don't Care / User Define / 3.5mm / 3.5mm(R&S))	Don't Care													
6	User Cal Kit Connect Type (Female)	Female													
7	User Cal Kit OPEN Item Title	OPEN Z0[ohm]	OPEN Delay[ps]	OPEN Loss[G ohm/s]	OPEN CO[e-15] F	OPEN OI[e-27] F/Hz	OPEN C2[e-36]	OPEN O3[e-46] F/Hz							
8	OPEN Calibration date	50	0	0	0	0	0	0							
9	User Cal Kit SHORT Item Title	SHORT Z0[ohm]	SHORT Delay[ps]	SHORT Loss[G ohm/s]	SHORT LO[e-12] H	SHORT LI[e-24] H/Hz	SHORT L2[e-3]	SHORT L3[e-42] H/Hz							
10	SHORT Calibration date	50	0	0	0	0	0	0							
11	User Cal Kit LOAD Item Title	LOAD Z0[ohm]	LOAD Delay[ps]	LOAD Loss	LOAD Resistance [ohm]										
12	LOAD Calibration date	50	0	0	50										
13	Number Of Channel	4													
14	Channel Title	CH1													
15	Waveform display	ON													
16	Measurement	S11													
17	DAL Method (Norm / 1 Port)	1 Port													
18	Settling of each port	PORT1													
19	Port Extension (psec)	0													
20	Port Impedance (ohm)	50													
21	Number of Freq Segment	1													
22	Segment Number	START[MHz]	STOP[MHz]	POINT	START POWER[dBm]	STOP POWER[dBm]	REBW[KHz]	SettlingTime[msec]							
23	Number of Trace	1	2400	2500	101	0	0	3							
24	Trace Number	1													
25	Format	FORMAT	/DIV	RefVAL	RefPos	Arrangement Number									
26	SWR	1		1	5	100	1								
27	Number of Measurement	1													
28	Measurement Number	TITLE	Units	Yak(O/N)/R	Trace Number	Meas. Command	START[MHz]	STOP[MHz]	Limit Disp	LowerLimit	UpperLimit	UpperLimit	Lw Freq[MHz]	Up Freq[MHz]	
29	1	S11 VS WR	ON		1	MAX	2400	2470	ON	ON	0	ON	2	2400	2470
30	Channel Title	CH2													
31	Waveform display	ON													
32	Measurement	S11													
33	DAL Method (Norm / 1 Port)	1 Port													
34	Settling of each port	PORT1													
35	Port Extension (psec)	0													
36	Port Impedance (ohm)	50													
37	Number of Freq Segment	1													
38	Segment Number	START[MHz]	STOP[MHz]	POINT	START POWER[dBm]	STOP POWER[dBm]	REBW[KHz]	SettlingTime[msec]							
39	Number of Trace	1	2400	2500	101	0	0	3							
40	Trace Number	1													
41	Format	FORMAT	/DIV	RefVAL	RefPos	Arrangement Number									
42	SWR	1		1	5	100	1								
43	Number of Measurement	1													
44	Measurement Number	TITLE	Units	Yak(O/N)/R	Trace Number	Meas. Command	START[MHz]	STOP[MHz]	Limit Disp	LowerLimit	UpperLimit	UpperLimit	Lw Freq[MHz]	Up Freq[MHz]	
45	1	S11 VS WR	ON		1	MAX	2400	2470	ON	ON	0	ON	2	2400	2470
46	Channel Title	CH3													
47	Waveform display	ON													
48	Measurement	S11													
49	DAL Method (Norm / 1 Port)	1 Port													
50	Settling of each port	PORT1													
51	Port Extension (psec)	0													
52	Port Impedance (ohm)	50													
53	Number of Freq Segment	1													
54	Segment Number	START[MHz]	STOP[MHz]	POINT	START POWER[dBm]	STOP POWER[dBm]	REBW[KHz]	SettlingTime[msec]							
55	Number of Trace	1	2400	2500	101	0	0	3							
56	Trace Number	1													
57	Format	FORMAT	/DIV	RefVAL	RefPos	Arrangement Number									
58	SWR	1		1	5	100	1								
59	Number of Measurement	1													
60	Measurement Number	TITLE	Units	Yak(O/N)/R	Trace Number	Meas. Command	START[MHz]	STOP[MHz]	Limit Disp	LowerLimit	UpperLimit	UpperLimit	Lw Freq[MHz]	Up Freq[MHz]	
61	1	S11 VS WR	ON		1	MAX	2400	2470	ON	ON	0	ON	2	2400	2470
62	Channel Title	CH4													
63	Waveform display	ON													
64	Measurement	S11													
65	DAL Method (Norm / 1 Port)	1 Port													
66	Settling of each port	PORT1													
67	Port Extension (psec)	0													
68	Port Impedance (ohm)	50													
69	Number of Freq Segment	1													
70	Segment Number	START[MHz]	STOP[MHz]	POINT	START POWER[dBm]	STOP POWER[dBm]	REBW[KHz]	SettlingTime[msec]							
71	Number of Trace	1	2400	2500	101	0	0	3							
72	Trace Number	1													
73	Format	FORMAT	/DIV	RefVAL	RefPos	Arrangement Number									
74	SWR	1		1	5	100	1								
75	Number of Measurement	1													
76	Measurement Number	TITLE	Units	Yak(O/N)/R	Trace Number	Meas. Command	START[MHz]	STOP[MHz]	Limit Disp	LowerLimit	UpperLimit	UpperLimit	Lw Freq[MHz]	Up Freq[MHz]	
77	1	S11 VS WR	ON		1	MAX	2400	2470	ON	ON	0	ON	2	2400	2470

Model, CAL correction values

Measurement conditions, measurement items, and limits for CH1

Measurement conditions, measurement items, and limits for CH2

Measurement conditions, measurement items, and limits for CH3

Measurement conditions, measurement items, and limits for CH4

### 3.1. Setting Measurement Condition File

Sample.xls								
	A	B	C	D	E	F	G	H
1	Application Name	ANT_Para						
2	CSV Sheet Revision	3						
3	Product Name	R3760						
4	CAL Data File Save/Recall	ON						
5	CAL Type (Don't Care / User Define / 3.5mm / 3.5mm(R&S))	Don't Care						
6	User Cal Kit Connect Type (Female)	Female						

(1) Application Name

ANT\_Para : Application software identification name.

(2) CSV Sheet Revision

3 : CSV revision

(3) Product Name

R3755A/R3760 : Board network analyzer to be connected

(4) CAL Data File Save/Recall

ON : Uses the calibration data Save/Recall function.

OFF : Does not use the calibration data Save/Recall function.

(5) CAL Type (Don't Care / User Define / 3.5mm / 3.5mm(R&S))

Don't Care : Specifies not to select a calibration type.

User Define : Specifies a user-specific calibration type. (The 6th, 8th, 10th, and 12th lines must also be set.)

3.5mm : Specifies 3.5mm for the calibration type.

A calibration value of the MAURY-produced CAL Kit (Model9617F3) is used.

3.5mm(R&S) : Specifies 3.5mm (R&S) for the calibration type.

A calibration value of the ROHDE&SCHWARZ-produced CAL Kit (ZV-Z132 MODEL 03) is used.

(6) User Cal Kit Connect Type (Female)

Female : Only this type can be specified.

Sample.xls								
	A	B	C	D	E	F	G	H
1	Application Name	ANT_Para						
2	CSV Sheet Revision	3						
3	Product Name	R3760						
4	CAL Data File Save/Recall	ON						
5	CAL Type (Don't Care / User Define / 3.5mm / 3.5mm(R&S))	Don't Care						
6	User Cal Kit Connect Type (Female)	Female						
7	User Cal Kit OPEN Item Title	OPEN Z0[ohm]	OPEN Delay[ps]	OPEN Loss[G ohm/s]	OPEN C0[e-15] F	OPEN C1[e-27] F/Hz	OPEN C2[e-36] F/Hz2	OPEN C3[e-45] F/Hz3
8	OPEN Calibration data	50	0	0	0	0	0	0
9	User Cal Kit SHORT Item Title	SHORT Z0[ohm]	SHORT Delay[ps]	SHORT Loss[G ohm/s]	SHORT L0[e-12] H	SHORT L1[e-24] H/Hz	SHORT L2[e-33] H/Hz2	SHORT L3[e-42] H/Hz3
10	SHORT Calibration data	50	0	0	0	0	0	0
11	User Cal Kit LOAD Item Title	LOAD Z0[ohm]	LOAD Delay[ps]	LOAD Loss	LOAD Resistance [ohm]			
12	LOAD Calibration data	50	0	0	50			

(7) User Cal Kit OPEN Item Title  
Setting title.

(8) OPEN Calibration data  
When CAL Type is User Define, set an OPEN correction value for this setting item.

(9) User Cal Kit SHORT Item Title  
Setting title.

(10) SHORT Calibration data  
When CAL Type is User Define, set a SHORT correction value for this setting item.

(11) User Cal Kit LOAD Item Title  
Setting title.

(12) LOAD Calibration data  
When CAL Type is User Define, set a LOAD correction value for this setting item.

(13)Number Of Channel

Specifies the total number of CHs (N) to be set.

	A	B	C	D	E	F	G	H	I	J	K	L	M	N	
13	Number Of Channel	4													
14	Channel Title	CH1													
15	Waveform display	ON													
16	Measurement	S11													
17	DAL Method (Norm / 1 Port)	1 Port													
18	Setting of each port	PORT1													
19	Port Extension (psec)	0													
20	Port Impedance (ohm)	50													
21	Number of Freq Segment	1													
22	Segment Number	START [MHz]	STOP [MHz]	POINT	START POWER [dBm]	STOP POWER [dBm]	RBW [KHz]	Settling Time [msec]							
23		1	2400	2500	101	0	0	3	0						
24	Number of Trace	1													
25	Trace Number	FORMAT	/DIV	RefVAL	RefPos	Arrangement Number									
26		1	SWR	1	5	100	1								
27	Number of Measurement	1													
28	Measurement Number	TITLE	Judge Valid (ON/Invalid/OFF)	Trace Number	Meas. Command	START [MHz]	STOP [MHz]	Limit Disp	Lower Limit Check	Lower Limit	Upper Limit Check	Upper Limit	Lw Freq [MHz]	Up Freq [MHz]	
29		1	S11 VSWR	ON	1	MAX	2400	2470	ON	ON	0	ON	2	2400	2470
30	Channel Title	CH2													
31	Waveform display	ON													
32	Measurement	S11													
33	DAL Method (Norm / 1 Port)	1 Port													
34	Setting of each port	PORT1													
35	Port Extension (psec)	0													
36	Port Impedance (ohm)	50													
37	Number of Freq Segment	1													
38	Segment Number	START [MHz]	STOP [MHz]	POINT	START POWER [dBm]	STOP POWER [dBm]	RBW [KHz]	Settling Time [msec]							
39		1	2400	2500	101	0	0	3	0						
40	Number of Trace	1													
41	Trace Number	FORMAT	/DIV	RefVAL	RefPos	Arrangement Number									
42		1	SWR	1	5	100	1								
43	Number of Measurement	1													
44	Measurement Number	TITLE	Judge Valid (ON/Invalid/OFF)	Trace Number	Meas. Command	START [MHz]	STOP [MHz]	Limit Disp	Lower Limit Check	Lower Limit	Upper Limit Check	Upper Limit	Lw Freq [MHz]	Up Freq [MHz]	
45		1	S11 VSWR	ON	1	MAX	2400	2470	ON	ON	0	ON	2	2400	2470
46	Channel Title	CH3													
47	Waveform display	ON													
48	Measurement	S11													
49	DAL Method (Norm / 1 Port)	1 Port													
50	Setting of each port	PORT1													
51	Port Extension (psec)	0													
52	Port Impedance (ohm)	50													
53	Number of Freq Segment	1													
54	Segment Number	START [MHz]	STOP [MHz]	POINT	START POWER [dBm]	STOP POWER [dBm]	RBW [KHz]	Settling Time [msec]							
55		1	2400	2500	101	0	0	3	0						
56	Number of Trace	1													
57	Trace Number	FORMAT	/DIV	RefVAL	RefPos	Arrangement Number									
58		1	SWR	1	5	100	1								
59	Number of Measurement	1													
60	Measurement Number	TITLE	Judge Valid (ON/Invalid/OFF)	Trace Number	Meas. Command	START [MHz]	STOP [MHz]	Limit Disp	Lower Limit Check	Lower Limit	Upper Limit Check	Upper Limit	Lw Freq [MHz]	Up Freq [MHz]	
61		1	S11 VSWR	ON	1	MAX	2400	2470	ON	ON	0	ON	2	2400	2470
62	Channel Title	CH4													
63	Waveform display	ON													
64	Measurement	S11													
65	DAL Method (Norm / 1 Port)	1 Port													
66	Setting of each port	PORT1													
67	Port Extension (psec)	0													
68	Port Impedance (ohm)	50													
69	Number of Freq Segment	1													
70	Segment Number	START [MHz]	STOP [MHz]	POINT	START POWER [dBm]	STOP POWER [dBm]	RBW [KHz]	Settling Time [msec]							
71		1	2400	2500	101	0	0	3	0						
72	Number of Trace	1													
73	Trace Number	FORMAT	/DIV	RefVAL	RefPos	Arrangement Number									
74		1	SWR	1	5	100	1								
75	Number of Measurement	1													
76	Measurement Number	TITLE	Judge Valid (ON/Invalid/OFF)	Trace Number	Meas. Command	START [MHz]	STOP [MHz]	Limit Disp	Lower Limit Check	Lower Limit	Upper Limit Check	Upper Limit	Lw Freq [MHz]	Up Freq [MHz]	
77		1	S11 VSWR	ON	1	MAX	2400	2470	ON	ON	0	ON	2	2400	2470

B13 :  
Number of  
set  
channels  
(N)

xN ←

### 3.2. Setting Measurement Conditions, Measurement Items, and Limits for Each CH

	A	B	C	D	E	F	G	H
14	Channel Title	CH1						
15	Waveform display	ON						
16	Measurement	S11						
17	CAL Method (Norm / 1 Port)	1 Port						
18	Setting of each port	PORT1						
19	Port Extension (psec)	0						
20	Port Impedance (ohm)	50						

(14) Channel Title  
CH title

(15) Waveform display  
ON : Displays waveforms.  
OFF : Does not display a waveform.

(16) Measurement  
S11 : S11 measurement (R3760)  
A/R : A/R measurement (R3755A)


(17) CAL Method (Norm / 1 Port)  
Norm : Sets Normalize for the calibration method.  
1 Port : Sets 1Port Full Cal for the calibration method.

(18) Setting of each port  
Setting of each port title.

(19) Port Extension (psec)  
Sets the electric length for port 1 by time. (The time unit is "setting value x 10E12".)

(20) Port Impedance (ohm)  
Sets a port impedance value.

	A	B	C	D	E	F	G	H	I
21	Number of Freq.Segment	1							
22	Segment Number	START[MHz]	STOP[MHz]	POINT	START POWER[dBm]	STOP POWER[dBm]	RBW[KHz]	SettlingTime[msec]	
23	1	2400	2500	101	0	0	3	0	
24	Number of Trace	1							
25	Trace Number	FORMAT	/DIV	RefVAL	RefPos	Arrangement Number			
26	1	SWR		1	5	100	1		
27	Number of Measurement	1							
28	Measurement Number	TITLE	Judge Valid(ON)/Invalid(OFF)	Trace Number	Meas. Command	START[MHz]	STOP[MHz]	Limit Disp	LowerLimit Check
29	1	S11 VSWR	ON	1	MAX	2400	2470	ON	ON



(21)Number of Freq.Segment

Sets the number of frequency settings for which segment sweep is performed.

(22)Segment Number

Segment sweep title.


(23) Number

Setting items specified for segment sweep.

Setting number, start frequency (MHz), stop frequency (MHz), number of measurement points, output power (start), output power (stop), RBW (KHz), and settling time (msec).

The preceding settings are repeated the number of times specified for "(21) Number of Freq. Segment."

	A	B	C	D	E	F	G	H	I
24	Number of Trace	1							
25	Trace Number	FORMAT	/DIV	RefVAL	RefPos	Arrangement Number			
26	1	SWR	1	5	100	1			
27	Number of Measurement	1							
28	Measurement Number	TITLE	Judge Valid(ON)/Invalid(OFF)	Trace Number	Meas. Command	START[MHz]	STOP[MHz]	Limit Disp	LowerLimit Check
29	1	S11 VSWR	ON	1	MAX	2400	2470	ON	ON




(24) Number of Trace  
Number of traces to be displayed.

(25) Trace Number  
Trace setting title

(26) Number  
Trace setting items.  
Trace format (LOGMAG, SWR, SMITH\*), scale (DIV), scale (Ref), and scale (Ref Position)  
\* The scale value of SMITH cannot be set up. (DIV = 1, Ref = 1, Ref Position = 100)  
Arrangement Number : 1, 2, 3, 4

The preceding settings are repeated the number of times specified for "(24) Number of Trace."

Arrangement Number : The example of specification



	A	B	C	D	E	F	G	H	I	J	K	L	M	N
27	Number of Measurement	1												
28	Measurement Number	TITLE	Judge Valid(ON)/Invalid(OFF)	Trace Number	Meas. Command	START[MHz]	STOP[MHz]	Limit Disp	LowerLimit Check	LowerLimit	UpperLimit Check	UpperLimit	Lw Freq[MHz]	Up Freq[MHz]
29	1	S11 VSWR	ON	1	MAX	2400	2470	ON	ON	0	ON	2	2400	2470

**B27 : Number of Measurement : The number of measurement items (M)**

- A29 : Measurement item number**
- B29 : Measurement item title**
- C29 : Judge(ON/OFF)**
- D29 : Target trace number**
- E29 : Method to obtain measurement value (MAX, MIN, VAL, PWRVAL, ...)**
- F29 : Measurement frequency (start MHz)**
- G29 : Measurement frequency (stop MHz)**
- H29 : Limit line display (ON/OFF)**
- I29 / K29 : Low/Up level limit check enable (ON)/disable (OFF)**
- J29 / L29 : Low/Up level limit value**
- M29 / N29 : Measurement frequency limit value  
(valid for numeric value other than 0)**

**xM** ←

(27) Number of Measurement  
Number of measurement points.

(28) Measurement Number  
Measurement item setting title.

## (29) Number

Sets conditions for measurement points.

Item name, total judgment enable/disable (ON/OFF), trace number, data acquisition method (MAX, MIN, VAL, PWRVAL, VAL\_L, VAL\_C, VAL\_R, RES\_MIN, RES\_L, RES\_C, RES\_R), data range setting (start), data range setting (stop), limit display setting (ON/OFF), Low limit check enable/disable (ON/OFF), Low limit value, Up limit check enable/disable (ON/OFF), Up limit value, Lw frequency limit value (zero: no limit, other than zero: limit setting), and Up frequency limit value (zero: no limit, other than zero: limit setting)

The preceding settings are repeated the number of times specified for "(27) Number of Measurement".

The following command is effective at the time of the format of SMITH. (3.1Setting Measurement Condition File (26)Number)

VAL\_L : It asks for L (inductance) of the start frequency.

VAL\_C : It asks for C (capacity) of the start frequency.

VAL\_R : It asks for R (resistance) of the start frequency.

RES\_MIN : the frequency of the minimum of a measured level is searched.

RES\_L : It asks for L (inductance) of the frequency searched by RES\_MIN. \*

RES\_C : It asks for C (capacity) of the frequency searched by RES\_MIN.\*

RES\_R : It asks for R (resistance) of the frequency searched by RES\_MIN.\*


\* Please specify the same set point as data range setting (start) of RES\_MIN, and data range setting (stop).

RES\_L : A Low limit value, Up limit value It is possible to attach and set up mH, uH, nH, and pH after a numerical value.


RES\_C : A Low limit value, Up limit value It is possible to attach and set up mF, uF, nF, and pF after a numerical value.

#### 4. Connecting ANT\_Para Application Software to R3755A/R3760

From the [Connect(C) ] menu, select [ ON (N) ] to connect to the R3755A/R3760.




When the connection is complete, the following Excel file selection window, different for each device type, is displayed.



#### 4.1. ANT\_Para Application Software Measurement Window.


The ANT\_Para application software measurement window is displayed as follows.



- |  |  |
|--|--|
| ① Connect (C) / Setup(S) / Test(T) / Ext Trg(E) / Lot(L) | Connect(C) : Menu to connect to the board network analyzer<br>Setup(S) : Communication setting menu.<br>Test(T) : Sweep (single / continuous) setting menu<br>Ext Trg(E) : External trigger setting menu<br>Lot(L) : Lot management setting menu |
| ② Measurement CH   | The setting CHs read from an Excel (CSV) file are displayed.   |
| ③ Measurement CH information                             | CHx Wave : Waveform display tab.<br>Setting : Measurement frequency condition display.<br>Measure : Measurement waveform type display, and scale setting.<br>Lot : Lot management setting.   |
| ④ Display Waveform display                               | Selected: A waveform is displayed.<br>Deselected: A waveform is not displayed.   |
| ⑤ Cal  | Checkbox : Calibration status ON/OFF.<br>[ ] : Calibration OFF<br>[ Cor ] : Calibration ON (normal status).<br>[ C? ] : Calibration ON (interpolation status)<br>[ C! ] : Calibration ON (extrapolation status)                                  |
| ⑥ Meas   | Measured-waveform display.   |
| ⑦ Judg   | Selected: PASS/FAIL is displayed.<br>Deselected: PASS/FAIL is not displayed.<br>PASS/FAIL display location setting.  |

## 4.2. Setting Tab


Measurement frequency settings can be checked, and also calibration data can be obtained or cleared.



For Cal Method, 1Port Cal or Normalize can be set depending on the specified Excel file (CSV).


## 4.3. Measure Tab

Measured waveforms can be checked, and also scale can be set.



#### 4.4. Lot Tab


Lot start/end for each CH can be controlled, and also device, PASS, and FAIL count values are displayed. Also, a save file name can be specified, and settings for saving trace data when FAIL occurs can be performed.




By operating the [START] and [END] buttons provided here, the measurement results from the [START] button execution and judgment results can be saved to a file for each count.

By clicking the [END] button, a file dialog box is displayed and measurement data can be saved with a name in the specified folder.

Also, an operation to execute lot start for all CHs is provided when multiple CHs are set. By selecting [ Start All (S) ] from [Lot(L) ] in the title menu, lot start can be executed for all CHs. Similarly, by selecting [ End All (E) ], lot end can be executed for all CHs. In this case, measurement data is saved with the name displayed in File Name.



□ When the Fail Data Save checkbox is selected, the measured waveform is automatically saved if the measurement value is Fail. The file name consists of a file name selected in the Excel file selection window different for each device type, to which year, month, date, time, and error count are added in this order.




Measured waveform data automatically generated if Fail occurs (Example)


S11xCH1_CH1_20110208_1204_0001.csv							
	A	B	C	D	E	F	G
1	No.	Freq	SWR				
2							
3	1	2.40E+09	5.11E+01				
4	2	2.40E+09	5.79E+01				
5	3	2.40E+09	6.73E+01				
6	4	2.40E+09	8.04E+01				
7	5	2.40E+09	1.02E+02				
8	6	2.41E+09	1.40E+02				
9	7	2.41E+09	2.65E+02				
10	8	2.41E+09	3.37E+02				
11	9	2.41E+09	5.76E+03				
12	10	2.41E+09	2.21E+02				
13	11	2.41E+09	2.78E+02				
14	12	2.41E+09	1.29E+02				
15	13	2.41E+09	9.92E+01				
16	14	2.41E+09	7.92E+01				
17	15	2.41E+09	9.32E+01				
18	16	2.42E+09	7.18E+01				
19	17	2.42E+09	5.78E+01				
20	18	2.42E+09	7.06E+01				
21	19	2.42E+09	4.94E+01				

#### 4.5. Starting Test

By selecting the [ Test(T) ] menu, measurement is executed one time.




[Ext Trigger ON(N)] : Measurement is executed for all CHs using the external trigger (parallel IF) input signal.




#### 4.6. Setup Menu

When an item within the [Setup(S)] menu is selected, a window to set items for connecting the R3755A/R3760 and Ext Trigger is displayed.




From the pull-down menu for BD, select an R3755A/R3760 board number recognized by NACServer. The IP address does not need to be changed. To use an external trigger, set 1. With this setting, measurement starts using an external trigger signal.



#### 4.7. Closing ANT\_Para

Select [OFF(F)] from the [ Connect(C)] menu.

※ For situations where [ON(N)] is selected in the [ Connect(C)] menu, ANT\_Para cannot terminate.



ANT\_Para can terminate by selecting [ X Close (C) Alt+F4] from the ANT\_Para icon menu, or clicking the [ X ] button on the right side of the window.



## 4.8. Measurement Result Format

By clicking the lot end button, a measurement result file is generated for each CH.

R3760_2p4GHz_x4CH_CH1.csv								
	A	B	C	D	E	F	G	H
1	Application Name	ANT_Para						
2	CSV Sheet Revision	3						
3	Board Number	0						
4	IP Address	127.0.0.1						
5	Product Name	R3760						
6	Serial Number	191100014						
7	-----	-----						
8	Total Count	6						
9	Pass Count	6		100%				
10	Fail Count	0		0%				
11	-----	-----		-----	-----	-----	-----	-----
12		No.	1				2	
13		CH Title	CH1				CH1	
14		Freq [MHz]	2300.000-2500.00				2300.000-2500.00	
15		Meas Title	S11 MIN				S11 L	
16		Freq			Level		Freq	
17		Upper Limit	-----			-15	-----	
18		Lower Limit	-----			-----	-----	
19		Fail Count	0		0		0	
20	-----	-----		-----	-----	-----	-----	-----
21	Measurement Count	Pass/Fail	Freq		Level		Freq	
22	1	Fail	2368000000		-27.817062		2368000000	
23	2	Fail	2376000000		-27.460571		2376000000	
24	3	Fail	2384000000		-28.326845		2384000000	
25	4	Fail	2392000000		-27.782093		2392000000	
26	5	Fail	2384000000		-27.664534		2384000000	
27	6	Pass	2488000000		-27.457401		2488000000	